

DTC U0534:68 [BLIND SPOT MONITORING (BSM)]

id0902i3393400

System malfunction location	Error signal received from BSM control module (RH)
Detection condition	• The BSM control module (LH) received an error signal from the BSM control module (RH).
Fail-safe	• BSM is stopped.
Possible cause	• BSM control module (RH) malfunction • BSM control module (LH) malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS BSM CONTROL MODULE (RH) • Clear the BSM control module (LH) DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].) • Perform the DTC inspection for the BSM control module (LH) using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].) • Is the DTC U0534:68 displayed?	Yes Replace the BSM control module (RH), then go to the next step. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to Step 3.
2	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS BSM CONTROL MODULE (LH) • Clear the BSM control module (LH) DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].) • Perform the DTC inspection for the BSM control module (LH) using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].) • Is the DTC U0534:68 displayed?	Yes Replace the BSM control module (LH), then go to the next step. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
3	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BLIND SPOT MONITORING (BSM)].)
		No DTC troubleshooting completed.