







# DTC B109F:87 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4013300

<b>System malfunction location</b>	<b>Communication error with intruder sensor</b>
<b>Detection condition</b>	<ul style="list-style-type: none"> <li>Rear body control module (RBCM) cannot receive signal from intruder sensor for <b>1.5 s or more</b>.</li> </ul>
<b>Fail-safe</b>	—
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>Short cord connector or terminal malfunction</li> <li>Rear body control module (RBCM) connector or terminal malfunction</li> <li>Short to ground in wiring harness between rear body control module (RBCM) terminal 1G and short cord terminal C</li> <li>Open circuit in wiring harness between rear body control module (RBCM) terminal 1G and short cord terminal C</li> <li>Intruder sensor malfunction</li> <li>Rear body control module (RBCM) malfunction</li> </ul>
<div> <div> RBCM  </div> <div> INTRUDER SENSOR  </div> </div> <div> SHORT CORD  </div> <div> RBCM WIRING HARNESS-SIDE CONNECTOR  </div> <div> SHORT CORD INTERIOR LIGHT HARNESS-SIDE CONNECTOR  </div> <div> INTRUDER SENSOR WIRING HARNESS-SIDE CONNECTOR  </div>	

## Diagnostic Procedure

Step	Inspection	Action
1	<b>VERIFY REAR BODY CONTROL MODULE (RBCM) DTCs AGAIN</b> <ul style="list-style-type: none"> <li>Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)</li> <li>Switch the ignition ON (engine off or on) and wait for <b>3 s or more</b>.</li> <li>Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)</li> <li>Is DTC B109F:87 displayed?</li> </ul>	<div>Yes</div> Go to the next step. <div>No</div> Go to Step 8.

Step	Inspection	Action	
2	<b>SHORT CORD CONNECTOR INSPECTION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Disconnect the short cord connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
3	<b>INSPECT REAR BODY CONTROL MODULE (RBCM) CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the rear body control module (RBCM) connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
4	<b>INSPECT INTRUDER SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the short cord and rear body control module (RBCM) connectors are disconnected.</li> <li>• Inspect for continuity between short cord terminal C (vehicle wiring harness side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness which is shorted to ground, then go to Step 7.
		No	Go to the next step.
5	<b>INSPECT INTRUDER SENSOR CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the short cord and rear body control module (RBCM) connectors are disconnected.</li> <li>• Inspect the wiring harness for an open circuit between rear body control module (RBCM) terminal 1G (vehicle wiring harness side) and short cord terminal C (vehicle wiring harness side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness which has an open circuit, then go to Step 7.
6	<b>INSPECT INTRUDER SENSOR</b> <ul style="list-style-type: none"> <li>• Inspect the intruder sensor. (See INTRUDER SENSOR INSPECTION.)</li> <li>• Is the intruder sensor normal?</li> </ul>	Yes	Go to the next step.
		No	Replace the intruder sensor, then go to the next step. (See INTRUDER SENSOR REMOVAL/INSTALLATION.)

Step	Inspection	Action
7	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>Reconnect all the disconnected connectors.</li> <li>Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)</li> <li>Switch the ignition ON (engine off or on) and wait for <b>3 s or more</b>.</li> <li>Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)</li> <li>Is DTC B109F:87 displayed?</li> </ul>	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
8	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>Are any other DTCs displayed?</li> </ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].)
		No DTC troubleshooting completed.