

SECURITY AND LOCKS PERSONALIZATION

id091400111100

- A personalization features that switches the activation/deactivation of each function has been adopted.
- The setting of the following system functions, and warning and guidance functions can be turned ON/OFF optionally.
- Refer to the Workshop Manual for the detailed setting procedure.

Advanced Keyless Entry System

Using Mazda Modular Diagnostic System (M-MDS)

M-MDS display	Function	Initial setting	Setting content	Control unit
Advanced keyless function. *1	The advanced keyless entry system and push button start system functions can be disabled.	Enabled	Enabled. / Disabled.	Start stop unit
Walk Away Lock.	The out-of-area (reception area) type auto lock function can be set.	OFF	Not Adopted. / OFF / ON	Start stop unit
Auto Re-lock Time.	The operation start time of the auto re-lock function can be changed.	30 seconds	Not Adopted. / 30 seconds / 60 seconds / 90 seconds	Start stop unit
Lock Beep Volume. *2	The keyless beeper volume can be adjusted.	Medium	Not Adopted. / Off / Low / Medium / High	Start stop unit

*1 : Because the push button start system function has been disabled, to start the engine press the upper part of the remote transmitter against the center of the push button start.

*2 : Settings can be changed by operation of the remote transmitter button. Refer to the Workshop Manual for the detailed setting procedure.

Using audio unit (with color LCD)

Audio unit display	Function	Initial setting	Setting content	Control unit
Walk Away Lock.	The out-of-area (reception area) type auto lock function can be set.	OFF	OFF / ON	Start stop unit
Auto Re-lock Time.	The operation start time of the auto re-lock function can be changed.	30 seconds	30 seconds / 60 seconds / 90 seconds	Start stop unit
Lock Beep Volume. *1	The keyless beeper volume can be adjusted.	Medium	Off / Low / Medium / High	Start stop unit

*1 : Settings can be changed by operation of the remote transmitter button. Refer to the Workshop Manual for the detailed setting procedure.

Keyless Entry System

Using Mazda Modular Diagnostic System (M-MDS)

M-MDS display	Function	Initial setting	Setting content	Control unit
Advanced keyless function. *1	The keyless entry system and push button start system functions can be disabled.	Enabled	Enabled. / Disabled.	Start stop unit
Auto Re-lock Time.	The operation start time of the auto re-lock function can be changed.	30 seconds	Not Adopted. / 30 seconds / 60 seconds / 90 seconds	Start stop unit

*1 : Because the push button start system function has been disabled, to start the engine press the upper part of the remote transmitter against the center of the push button start.

Using audio unit (with color LCD)

Audio unit display	Function	Initial setting	Setting content	Control unit
Auto Re-lock Time.	The operation start time of the auto re-lock function can be changed.	30 seconds	30 seconds / 60 seconds / 90 seconds	Start stop unit

Power Door Lock System

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Auto Door Lock Mode	Auto door lock function can be changed.	Lock: Driving, Unlock: IGN Off	Not Adopted. / OFF / Lock When Driving. / Lock: Driving, Unlock: IGN Off. / Lock When Shifting Out Of P. / Lock: Shift From P, Unlock: In P.	Rear body control module (RBCM)