
AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0]

id0102h1801100

1. Switch the ignition to off.
2. Connect the M-MDS to the DLC-2.
3. Switch the ignition ON (engine off).
4. Verify the DTC according to the directions on the M-MDS screen.
 - Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition off (LOCK) and continue it for **30 s or more**.

Caution

- **Always switch the ignition off (LOCK) after clearing the DTC.**
- **If the engine is accidentally started, disconnect the negative battery cable and reconnect it. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0 (WITHOUT i-stop)].)**

6. Switch the ignition ON (engine on).
7. Verify all accessory loads are off.
8. Start the engine and maintain the engine speed at **2,800—3,200 rpm** until the cooling fan starts running (for A/F sensor and HO2S activation).
9. When the cooling fan starts running, idle the engine.
10. Maintain the idle status for **30 s or more** after the cooling fan has stopped (for fuel learning).
11. Perform the DTC inspection again and verify that no DTCs are stored. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].)
12. Switch the ignition to off.
13. Disconnect the M-MDS to the DLC-2.