

DTC: B116A:44, 26:Er86 [Bluetooth SYSTEM (HANDS-FREE TELEPHONE (HF/TEL) SYSTEM)]

id0902g8440400

Description	Bluetooth unit internal malfunction
Detection condition	Bluetooth unit internal malfunction detected
Fail-safe function	—
Possible cause	Bluetooth unit malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action	
1	PERFORM INSPECTION OF BLUETOOTH UNIT DTCs • Perform an inspection of the Bluetooth unit DTCs. (See DTC INSPECTION [Bluetooth SYSTEM (HANDS-FREE TELEPHONE (HF/TEL) SYSTEM)].) • Is the same DTC displayed?	Yes	Replace the Bluetooth unit, then go to the next step. (See Bluetooth UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [Bluetooth SYSTEM (HANDS-FREE TELEPHONE (HF/TEL) SYSTEM)].)
		No	DTC troubleshooting completed.