

THE BSM INDICATOR LIGHT DOES NOT FLASH OR ILLUMINATE CONTINUOUSLY, BUT A TURN SIGNAL IS ON [BLIND SPOT MONITORING (BSM)]

id0903d9015700

Description	The BSM indicator light does not flash or illuminate continuously, but a turn signal is ON
	<ul style="list-style-type: none"> • BSM warning alarm sounds but BSM indicator light does not flash • BSM warning alarm is triggered on side opposite to the direction in which turn signal is operated
Possible Causes	<ul style="list-style-type: none"> • Instrument cluster receives incorrect BSM warning alarm request signal <ul style="list-style-type: none"> — Communication error between BSM control module and instrument cluster — Instrument cluster malfunction

Diagnostic Procedure

Step	Inspection	Result	Action
1	INSPECT BSM WARNING ALARM <ul style="list-style-type: none"> • Turn off the BSM using the M-MDS instrument cluster active command modes ALARM. (See ACTIVE COMMAND MODES TABLE [INSTRUMENT CLUSTER].) • Does the BSM turn off according to the active command models? 	Yes	Go to the next step.
		No	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
2	VERIFY DTCs <ul style="list-style-type: none"> • Retrieve DTCs from the BSM control module and instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].) • Are any DTCs displayed? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].) (See DTC TABLE [BLIND SPOT MONITORING (BSM)].)
		No	Go to the next step.
3	VERIFY BSM INDICATOR LIGHT CONDITION <ul style="list-style-type: none"> • Verify the BSM indicator light illumination condition while under the BSM indicator light-illumination conditions (vehicle speed above 32 km/h {20 mph} or more, turn signals off, and vehicle in warning zone). • Does the BSM indicator light illuminate normally? 	Yes	Replace the BSM control module. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/ INSTALLATION.)
		No	Go to the symptom troubleshooting procedure, "BSM indicator light does not illuminate while under BSM indicator light-illumination conditions". (See BSM INDICATOR LIGHT DOES NOT ILLUMINATE WHILE UNDER BSM INDICATOR LIGHT-ILLUMINATION CONDITIONS [BLIND SPOT MONITORING (BSM)].)