


## DTC P2502:00 [SKYACTIV-D 2.2]

id0102s4709500

### Details On DTCs

| DESCRIPTION                                  | Generator system: Malfunction in voltage generated by generator   |   |
|--|---|---|
| DETECTION<br>CONDITION                       | Determination conditions  | • The voltage generated by the generator is <b>17 V or higher</b> and the battery voltage is <b>11 V or less</b> for a continuous specified time. |
|  | Preconditions   | • While engine is running   |
|  | Malfunction determination period  | • <b>5 s</b> period   |
|  | Drive cycle   | • 1   |
|  | Self test type  | • CMDTC self test   |
|  | Sensor used   | • PCM<br>• Generator  |
| FAIL-SAFE<br>FUNCTION                        | <ul style="list-style-type: none"> <li>• Inhibits engine-stop by operating the i-stop function.</li> <li>• Generator control is inhibited.</li> </ul>   |   |
| VEHICLE<br>STATUS WHEN<br>DTCs ARE<br>OUTPUT | <ul style="list-style-type: none"> <li>• Flashes i-stop warning light (amber).</li> <li>• A warning message is displayed on the TFT LCD in the instrument cluster. (With TFT LCD)</li> <li>• Illuminates charging system warning light. (Without TFT LCD)</li> <li>• If the vehicle continues to be driven while the DTC is detected the battery will be depleted. <ul style="list-style-type: none"> <li>— A malfunction occurs with an electrical device and the vehicle stops.</li> </ul> </li> <li>• The following vehicle conditions differ depending on the type of malfunction: <ul style="list-style-type: none"> <li>— Vehicle shock may occur due to generator load.</li> <li>— Idling feel due to generator-stop may occur.</li> </ul> </li> </ul>   |   |
| POSSIBLE<br>CAUSE                            | <ul style="list-style-type: none"> <li>• Poor connection of the following parts: <ul style="list-style-type: none"> <li>— Battery</li> <li>— Generator</li> <li>— PCM</li> </ul> </li> <li>• Connector or terminal malfunction of the following parts: <ul style="list-style-type: none"> <li>— Battery</li> <li>— Generator</li> <li>— PCM</li> </ul> </li> <li>• Short to ground or open circuit in generator charge/discharge circuit <ul style="list-style-type: none"> <li>— Short to ground in wiring harness between battery positive terminal and generator terminal 1A</li> <li>— STARTER 450 A fuse malfunction</li> <li>— Open circuit in wiring harness between battery positive terminal and generator terminal 1A</li> </ul> </li> <li>• Generator malfunction</li> <li>• Battery malfunction</li> <li>• PCM malfunction</li> </ul> |   |

## System Wiring Diagram



ac5wzw00006566

### Function Explanation (DTC Detection Outline)

- When the charge/discharge circuit for the power supplying the vehicle is normal, the vehicle will operate normally. In this diagnostic, a low vehicle supply voltage is detected even though the generator is generating power, a malfunction in the charge/discharge circuit is detected, and verification of vehicle malfunctions/safety assurance is performed.

### Repeatability Verification Procedure

- Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)
- Start the engine.
- Leave for **180 s** while idling with no electrical load.
- Leave for **30 s** while idling with high electrical load.

### PID Item/Simulation Item Used In Diagnosis

- Not applicable

### Troubleshooting Diagnostic Procedure

#### Intention of troubleshooting procedure

- Step 1—6
  - Perform an inspection of each signal transmission system.
- Step 7
  - Perform a unit inspection of the generator.
- Step 8—10
  - Verify that the primary malfunction is resolved and there are no other malfunctions.

| STEP | INSPECTION  | RESULTS | ACTION  |
|------|---|---------|---|
| 1    | <b>PURPOSE: VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>• Verify related Service Information availability.</li> <li>• Is any related Service Information available?</li> </ul>   | Yes     | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, go to the next step.   |
|      |   | No      | Go to the next step.  |
| 2    | <b>PURPOSE: VERIFY IF POOR CONNECTION OF EACH PART AFFECTS DIAGNOSTIC RESULTS</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Inspect the connection condition (part installation condition, connector connection condition) for the following parts: <ul style="list-style-type: none"> <li>— Battery</li> <li>— Generator</li> <li>— PCM</li> </ul> </li> <li>• Is the connection condition (part installation condition, connector connection condition) for each part normal?</li> </ul> | Yes     | Go to the next step.  |
|      |   | No      | Connect each part or the connector correctly, then go to Step 8.  |
| 3    | <b>PURPOSE: VERIFY IF CONNECTOR DAMAGE OF EACH PART AFFECTS DIAGNOSTIC RESULTS</b> <ul style="list-style-type: none"> <li>• Disconnect the connector of the following parts. <ul style="list-style-type: none"> <li>— Battery</li> <li>— Generator</li> <li>— PCM</li> </ul> </li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>  | Yes     | Repair or replace the connector and/or terminals, then go to Step 8.  |
|      |   | No      | Go to the next step.  |
| 4    | <b>PURPOSE: INSPECT FUSE</b> <ul style="list-style-type: none"> <li>• Remove the STARTER 450 A fuse.</li> <li>• Inspect the STARTER 450 A fuse.</li> <li>• Is there any malfunction?</li> </ul>   | Yes     | If the fuse is burnt out: <ul style="list-style-type: none"> <li>• Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and generator terminal 1A.</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>— Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>— Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness which has a short to ground.</li> <li>— Replace the malfunctioning fuse.</li> </ul> If the fuse is damaged: <ul style="list-style-type: none"> <li>• Replace the fuse.</li> </ul> Go to Step 8. |
|      |   | No      | Reinstall the STARTER 450 A fuse, then go to the next step.   |
| 5    | <b>PURPOSE: VERIFY IF SHORT TO GROUND IN GENERATOR CHARGE/DISCHARGE CIRCUIT AFFECTS DIAGNOSTIC RESULTS</b> <ul style="list-style-type: none"> <li>• Verify that the battery, generator and PCM connectors are disconnected.</li> <li>• Inspect for continuity between generator terminal 1A (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>   | Yes     | Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and generator terminal 1A. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> Go to Step 8.   |
|      |   | No      | Go to the next step.  |

| STEP | INSPECTION   | RESULTS | ACTION   |
|------|--|---------|--|
| 6    | <b>PURPOSE: VERIFY IF OPEN CIRCUIT IN GENERATOR CHARGE/DISCHARGE CIRCUIT AFFECTS DIAGNOSTIC RESULTS</b> <ul style="list-style-type: none"> <li>Verify that the battery, generator and PCM connectors are disconnected.</li> <li>Inspect for continuity between battery positive terminal (wiring harness-side) and generator terminal 1A (wiring harness-side).</li> <li>Is there continuity?</li> </ul>   | Yes     | Go to the next step.   |
|      |  | No      | Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and generator terminal 1A.<br><b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 8. |
| 7    | <b>PURPOSE: DETERMINE INTEGRITY OF GENERATOR</b> <ul style="list-style-type: none"> <li>Inspect the generator.<br/>(See GENERATOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>  | Yes     | Replace the generator, then go to the next step.<br>(See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)   |
|      |  | No      | Go to the next step.   |
| 8    | <b>PURPOSE: VERIFY CONDITIONS OF BATTERY</b> <ul style="list-style-type: none"> <li>Inspect the battery.<br/>(See BATTERY INSPECTION [SKYACTIV-D 2.2].)</li> </ul>   | —       | Follow the inspection instructions, then go to the next step.  |
| 9    | <b>PURPOSE: VERIFICATION OF VEHICLE REPAIR COMPLETION</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS.<br/>(See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Implement the repeatability verification procedure.<br/>(See Repeatability Verification Procedure.)</li> <li>Perform the DTC Reading Procedure.<br/>(See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>Is the same DTC present?</li> </ul> | Yes     | Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM.<br/>(See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to the next step.   |
|      |  | No      | Go to the next step.   |
| 10   | <b>PURPOSE: VERIFY IF THERE IS ANY OTHER MALFUNCTION</b> <ul style="list-style-type: none"> <li>Is any other DTC or pending code stored?</li> </ul>  | Yes     | Go to the applicable DTC inspection.<br>(See DTC TABLE [SKYACTIV-D 2.2].)  |
|      |  | No      | DTC troubleshooting completed.   |