

## DTC P1282:00 [SKYACTIV-D 2.2]

id0102s4214200

DTC P1282:00	Common rail control system problem
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>When the following conditions are met, the common rail fuel pressure value <b>exceeds 250 MPa {2,549 kgf/cm<sup>2</sup>, 36,260 psi}</b> or the fuel pressure value exceeds the value calculated by the PCM based on the engine speed for a continuous <b>1 s</b>.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>Engine speed: <b>above 500 rpm</b></li> <li>Battery voltage: <b>8—20 V</b></li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is an intermittent monitor (fuel system).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM.</li> <li>PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>PCM restricts engine torque.</li> <li>Increase the idle speed.</li> <li>Inhibits the diesel particulate filter regeneration control.</li> <li>Inhibits engine-stop by operating the i-stop function.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Fuel filter clogged</li> <li>Fuel pressure relief valve malfunction</li> <li>Fuel pressure sensor malfunction</li> <li>Suction control valve malfunction</li> <li>Fuel pipe perforation or breakage (poor contact)</li> <li>PCM malfunction</li> </ul>
<b>SYSTEM WIRING DIAGRAM</b>	Not applicable

### Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> <ul style="list-style-type: none"> <li>Switch the ignition off, then ON (engine off).</li> <li>Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>Are any other PENDING CODEs and/or DTCs present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	<b>VERIFY CURRENT INPUT SIGNAL STATUS IS CONCERN INTERMITTENT OR CONSTANT</b> <ul style="list-style-type: none"> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Start the engine.</li> <li>Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Go to the next step.
		No	Intermittent concern exists. • Perform the "INTERMITTENT CONCERN TROUBLESHOOTING" procedure. (See INTERMITTENT CONCERN TROUBLESHOOTING [SKYACTIV-D 2.2].)

STEP	INSPECTION		ACTION
5	<b>INSPECT FUEL FILTER FOR CLOGGING</b> <ul style="list-style-type: none"> <li>Visually inspect the fuel filter. (See FUEL FILTER INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 10. (See FUEL FILTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
6	<b>INSPECT FUEL PRESSURE RELIEF VALVE</b> <ul style="list-style-type: none"> <li>Inspect the fuel pressure relief valve. (See FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the common rail, then go to Step 10. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
7	<b>INSPECT FUEL PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the common rail, then go to Step 10. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
8	<b>INSPECT SUCTION CONTROL VALVE</b> <ul style="list-style-type: none"> <li>Inspect the suction control valve. (See SUCTION CONTROL VALVE INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the suction control valve, then go to Step 10. (See SUCTION CONTROL VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
9	<b>INSPECT FUEL LINE</b> <ul style="list-style-type: none"> <li>Inspect the fuel line. (See FUEL SYSTEM LOCATION INDEX [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step.
		No	Go to the next step.
10	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Start the engine and warm it up completely.</li> </ul> <p><b>Caution</b></p> <ul style="list-style-type: none"> <li>While performing this step, always operate the vehicle in a safe and lawful manner.</li> <li>When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later.</li> </ul> <ul style="list-style-type: none"> <li>Drive the vehicle under the FREEZE FRAME DATA (Mode 2)/snapshot data condition.</li> <li>Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
11	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.