

NON-RETURN VALVE [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0114z9188800


Purpose, Function

- Assures safety by preventing fuel from returning to the fuel filler opening.

Construction


- The non-return valve cannot be removed as it is installed inside the fuel tank.

2WD




ac5uun00000058

4WD



ac5uun00000059


- A single valve type has been adopted for the non-return valve.



ac5uun00000060

Operation

- Normally, the valve is closed as shown by the dotted line in the figure. When refueling, it opens as shown by the solid line due to the force caused by the flow of fuel. When refueling is finished, the valve returns to the normal valve position by spring force.



ac5uun00000061