



| DTC P2455:00 | Exhaust gas pressure sensor No.2 circuit high input |
|--------------------------------|---|
| DETECTION CONDITION | <ul style="list-style-type: none"> If the input voltage at the PCM terminal 1Z is more than 4.81 V for 30 s, the PCM determines that the exhaust gas pressure sensor No.2 circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory. |
| FAIL-SAFE FUNCTION | <ul style="list-style-type: none"> PCM restricts engine torque. Inhibits the EGR control. Inhibits the diesel particulate filter regeneration control. Inhibits engine-stop by operating the i-stop function. PCM restricts engine-transaxle integration control. |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> Exhaust gas pressure sensor No.2 connector or terminals malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between exhaust gas pressure sensor No.2 terminal C and PCM terminal 1Z Exhaust gas pressure sensor No.2 power supply circuit and signal circuit are shorted to each other Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Exhaust gas pressure sensor No.2 terminal C—PCM terminal 1Z Exhaust gas pressure sensor No.2 terminal B—PCM terminal 1AE Exhaust gas pressure sensor No.2 malfunction PCM malfunction |



Diagnostic Procedure

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 1 | VERIFY FREEZE FRAME DATA (MODE 2)/SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded? | Yes | Go to the next step. |
| | | No | Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step. |
| 2 | VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. |
| | | No | Go to the next step. |
| 3 | INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the exhaust gas pressure sensor No.2 connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? | Yes | Repair or replace the connector and/or terminals, then go to Step 9. |
| | | No | Go to the next step. |
| 4 | INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? | Yes | Repair or replace the connector and/or terminals, then go to Step 9. |
| | | No | Go to the next step. |
| 5 | INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the exhaust gas pressure sensor No.2 and PCM connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the exhaust gas pressure sensor No.2 terminal C (wiring harness-side). Is the voltage 0 V? | Yes | Go to the next step. |
| | | No | Repair or replace the wiring harness for a possible short to power supply, then go to Step 9. |
| 6 | INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 POWER SUPPLY CIRCUIT AND SIGNAL CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> Verify that the exhaust gas pressure sensor No.2 and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between exhaust gas pressure sensor No.2 terminals A and C (wiring harness-side). Is there continuity? | Yes | Repair or replace the wiring harness for a possible short to each other, then go to Step 9. |
| | | No | Go to the next step. |
| 7 | INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the exhaust gas pressure sensor No.2 and PCM connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Exhaust gas pressure sensor No.2 terminal C—PCM terminal 1Z Exhaust gas pressure sensor No.2 terminal B—PCM terminal 1AE Is there continuity? | Yes | Go to the next step. |
| | | No | Repair or replace the wiring harness for a possible open circuit, then go to Step 9. |
| 8 | INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the exhaust gas pressure sensor No.2. (See EXHAUST GAS PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? | Yes | Replace the exhaust gas pressure sensor No.2, then go to the next step. (See EXHAUST GAS PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) |
| | | No | Go to the next step. |
| 9 | VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) Is the same DTC present? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step. |
| | | No | Go to the next step. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 10 | VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Are any DTCs present? | Yes | Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].) |
| | | No | DTC troubleshooting completed. |