

---

## DOWN SWITCH REMOVAL/INSTALLATION [GW6A-EL, GW6AX-EL]

id0517i2112300

### **Note**

- The down switch is built into the selector lever component.
1. If the down switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)