

---

## ROLLOVER VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0116e1804600

### **Note**

- The rollover valve cannot be removed as it is built into the fuel tank.

1. Remove the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)