




DTC P2033:00	Exhaust gas temperature sensor No.2 circuit high input
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>• The PCM monitors the exhaust gas temperature sensor No.2 signal. If the PCM detects that the exhaust gas temperature sensor No.2 voltage at the PCM terminal 1CA is <b>above 4.96 V</b> for <b>3 s</b>, the PCM determines that the exhaust gas temperature sensor No.2 circuit has a malfunction.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>— Battery voltage: <b>8—20 V</b></li> <li>— Between the elapsed time of 18 to 70 min. after the ignition is switched on (engine on).</li> <li>— Engine speed: <b>above 700 rpm</b></li> <li>— Engine coolant temperature: <b>above 60 °C {140 °F}</b></li> <li>— Intake air temperature: <b>above 5 °C {41 °F}</b></li> <li>— Vehicle speed: <b>above 25 km/h {16 mph}</b> continues for <b>10 min or more</b></li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>• This is a continuous monitor (CCM).</li> <li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>• DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>• PCM restricts engine torque.</li> <li>• Inhibits the EGR control.</li> <li>• Inhibits the diesel particulate filter regeneration control.</li> <li>• The fast idle up correction for the idle speed control is inhibited.</li> <li>• Inhibits engine-stop by operating the i-stop function.</li> <li>• PCM restricts engine-transaxle integration control.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• Exhaust gas temperature sensor No.2 connector or terminals malfunction</li> <li>• PCM connector or terminals malfunction</li> <li>• Short to power supply in wiring harness between exhaust gas temperature sensor No.2 terminal A and PCM terminal 1CA</li> <li>• Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>— Exhaust gas temperature sensor No.2 terminal A—PCM terminal 1CA</li> <li>— Exhaust gas temperature sensor No.2 terminal B—PCM terminal 1CB</li> </ul> </li> <li>• Exhaust gas temperature sensor No.2 malfunction</li> <li>• PCM malfunction</li> </ul>

**DTC  
P2033:00**

**Exhaust gas temperature sensor No.2 circuit high input**



PCM WIRING HARNESS-SIDE CONNECTOR



**Diagnostic Procedure**

STEP	INSPECTION	ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"><li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot been recorded?</li></ul>	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"><li>Verify related Service Information availability.</li><li>Is any related Service Information available?</li></ul>	Yes Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"><li>If the vehicle is not repaired, go to the next step.</li></ul>
		No Go to the next step.
3	<b>INSPECT EXHAUST GAS TEMPERATURE SENSOR NO.2 CONNECTOR CONDITION</b> <ul style="list-style-type: none"><li>Switch the ignition off.</li><li>Disconnect the exhaust gas temperature sensor No.2 connector.</li><li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li><li>Is there any malfunction?</li></ul>	Yes Repair or replace the connector and/or terminals, then go to Step 8.
		No Go to the next step.
4	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"><li>Disconnect the PCM connector.</li><li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li><li>Is there any malfunction?</li></ul>	Yes Repair or replace the connector and/or terminals, then go to Step 8.
		No Go to the next step.

STEP	INSPECTION	ACTION	
5	<b>INSPECT EXHAUST GAS TEMPERATURE SENSOR NO.2 SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the exhaust gas temperature sensor No.2 and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> <li>• Measure the voltage at the exhaust gas temperature sensor No.2 terminal A (wiring harness-side).</li> <li>• Is the voltage <b>0 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
6	<b>INSPECT EXHAUST GAS TEMPERATURE SENSOR NO.2 CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the exhaust gas temperature sensor No.2 and PCM connectors are disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Exhaust gas temperature sensor No.2 terminal A—PCM terminal 1CA</li> <li>— Exhaust gas temperature sensor No.2 terminal B—PCM terminal 1CB</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
7	<b>INSPECT EXHAUST GAS TEMPERATURE SENSOR NO.2</b> <ul style="list-style-type: none"> <li>• Reconnect all disconnected connectors.</li> <li>• Inspect the exhaust gas temperature sensor No. 2. (See EXHAUST GAS TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the exhaust gas temperature sensor No.2, then go to the next step. (See EXHAUST GAS TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Perform the Drive Mode Type B. (See OBD DRIVE MODE [SKYACTIV-D 2.2].)</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.