

---

## FUEL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7801200

### Note

- The fuel pressure sensor cannot be removed as a single unit. When replacing the fuel pressure sensor, replace it together with the common rail as a single unit.

1. Remove the common rail. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)