

PID/DATA MONITOR TABLE [FULL-AUTO AIR CONDITIONER]

id0702c1801900

PID name (definition)	Unit/Condition	Operation Status (Reference)	Input part
A/C_SW	Off/On	<ul style="list-style-type: none"> A/C switch OFF: Off A/C switch ON: On 	Climate control unit
AUTO_SW	Off/On	<ul style="list-style-type: none"> AUTO switch OFF: Off AUTO switch ON: On 	Climate control unit
B_MT_RLY_CS	Off/On	<ul style="list-style-type: none"> Blower relay off: Off Blower relay on: On 	Climate control unit
DEF_SW	Off/On	<ul style="list-style-type: none"> DEFROSTER switch OFF: Off DEFROSTER switch ON: On 	Climate control unit
DUAL_SW	Off/On	<ul style="list-style-type: none"> DUAL switch OFF: Off DUAL switch ON: On 	Climate control unit
ELE_W/P	Off/On	<ul style="list-style-type: none"> Water pump off: Off Water pump on: On 	Water pump ^{*1}
ENG_C_TMP	°C, °F	Engine coolant temperature is displayed	Engine coolant temperature sensor
EVA_TMP_SEN	°C, °F	Evaporator temperature is displayed	Evaporator temperature sensor
F_REC_CS	Off/On	<ul style="list-style-type: none"> Forced recirculate control off: Off Forced recirculate control on: On 	Climate control unit
FRE_SW	Off/On	<ul style="list-style-type: none"> FRESH switch OFF: Off FRESH switch ON: On 	Climate control unit
HC_TMP_SEN	°C, °F	Heater core temperature is displayed	Heater core temperature sensor ^{*2}
INC_TMP_SEN	°C, °F	Cabin temperature is displayed	Cabin temperature sensor
M_DOWN_SW	Off/On	<ul style="list-style-type: none"> MODE switch (DOWN) OFF: Off MODE switch (DOWN) ON: On 	Climate control unit
M_UP_SW	Off/On	<ul style="list-style-type: none"> MODE switch (UP) OFF: Off MODE switch (UP) ON: On 	Climate control unit
OFF_SW	Off/On	<ul style="list-style-type: none"> OFF switch OFF: Off OFF switch ON: On 	Climate control unit
OUT_CAR_TMP	°C, °F	Ambient temperature is displayed	Ambient temperature sensor
R/DEF_CS	Off/On	<ul style="list-style-type: none"> Rear defroster off: Off Rear defroster on: On 	Climate control unit
R/DEF_SW	Off/On	<ul style="list-style-type: none"> Rear window defroster switch OFF: Off Rear window defroster switch ON: On 	Climate control unit
REC_SW	Off/On	<ul style="list-style-type: none"> RECIRCULATE switch OFF: Off RECIRCULATE switch ON: On 	Climate control unit
S_HT_CUT_CS	No_Request/Cut	<ul style="list-style-type: none"> Seat warmer signal cut control off: No_Request Seat warmer signal cut control on: Cut 	Climate control unit
SLR_R_SEN_L SLR_R_SEN_R	W	Solar radiation amount is displayed	Solar radiation sensor
STOP_ST	Available/ Not Available/ Error	<ul style="list-style-type: none"> i-stop permit condition: Available i-stop inhibit condition: Not Available i-stop signal failure: Error 	<ul style="list-style-type: none"> Climate control unit PCM
UNIT_TMP	deg_C/deg_F	<ul style="list-style-type: none"> Centigrade: deg_C Fahrenheit: deg_F 	Climate control unit

^{*1} : With water pump

^{*2} : With heater core temperature sensor