

FORWARD SENSING CAMERA (FSC) PERSONALIZATION FEATURES SETTING PROCEDURE

id092200033700

High Beam Control (HBC) System

1. Connect the M-MDS to the DLC-2.
2. After vehicle identification, select the following from the M-MDS initialization screen.
 - (1) "Module programming"
 - (2) "Programmable Parameters"
3. Select menu in the "FSC".
4. Select an item name, and then select option.

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
High Beam Control.	The high beam control (HBC) system can be disabled.	ON	Not Adopted. / OFF / ON	FSC

Lane Departure Warning System (LDWS)

Note

- For personalization of the warning sound and volume, refer to the INSTRUMENT CLUSTER PERSONALIZATION FEATURES SETTING PROCEDURE. (See INSTRUMENT CLUSTER PERSONALIZATION FEATURES SETTING PROCEDURE.)

Using M-MDS

1. Connect the M-MDS to the DLC-2.
2. After vehicle identification, select the following from the M-MDS initialization screen.
 - (1) "Module programming"
 - (2) "Programmable Parameters"
3. Select menu in the "FSC".
4. Select an item name, and then select option.

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
LDWS Timing.	The warning operation timing of the lane departure warning system (LDWS) can be changed.	Adaptive	Not Adopted / Adaptive / Early / Medium / Late	FSC
LDWS Warning.	The warning operation sensitivity of the lane departure warning system (LDWS) can be changed.	Medium	Not Adopted. / Often / Medium / Rare	FSC

Using instrument cluster (with TFT LCD only)

1. Switch the ignition ON (engine off or on).
2. Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
3. Select "LDWS" by operating the up/down switch and INFO switch for the steering switch.
4. Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Timing	The warning operation timing of the lane departure warning system (LDWS) can be changed.	Adaptive	Early / Medium / Late / Adaptive	FSC
Warning	The warning operation sensitivity of the lane departure warning system (LDWS) can be changed.	Medium	Often / Medium / Rare	FSC