

## DTC U3000:49

id080200824800

<b>System malfunction location</b>	• SAS control module internal malfunction
<b>Detection condition</b>	<b>Warning</b> <ul style="list-style-type: none"><li>• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.</li></ul> • SAS control module internal circuit has a malfunction
<b>Fail-safe</b>	—
<b>Possible cause</b>	• SAS control module malfunction
<b>System wiring diagram</b>	—

### Diagnostic Procedure

<b>ACTION</b>
• Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION.)