

NO.1 BLOWN FUSES [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0103g3507100

1	BLOWN FUSES
[TROUBLESHOOTING HINTS] • Inspect condition of fuse.	

Damaged fuse	Related wiring harness
MAIN	<ul style="list-style-type: none"> • FAN GE fuse • ADD FAN GE fuse • FUEL PUMP fuse • IG2 fuse • ENG.+B fuse • ENG.MAIN fuse • INJECTOR fuse • EVVT fuse • IG1 relay
FAN GE	• Cooling fan relay No.1
ADD FAN GE	• Cooling fan relay No.3
ENGINE.IG1	<ul style="list-style-type: none"> • Fuel pump relay • PCM
FUEL PUMP	• Fuel pump relay
STARTER	<ul style="list-style-type: none"> • Generator • Starter
DCDC*1	• DC-DC converter
AUDIO2	• Ignition relay (ACC_STAB)*1
METER2*1	• Ignition relay (IG1_STAB)
C/U IG1	<ul style="list-style-type: none"> • DC-DC converter*1 • Ignition relay (IG1_STAB)*1
IG2	<ul style="list-style-type: none"> • ACC relay • Starter relay
ENG.+B	<ul style="list-style-type: none"> • Current sensor*1 • PCM • DLC-2
ENG.MAIN	• Main relay
INJECTOR	• Fuel injector relay
EVVT	• Electric variable valve timing relay
ENGINE1	<ul style="list-style-type: none"> • Electric variable valve timing relay • A/F sensor • HO2S • MAF sensor/IAT sensor No.1 • Intake CMP sensor

Damaged fuse	Related wiring harness
ENGINE2	<ul style="list-style-type: none"> • Fuel injector relay • Purge solenoid valve • OCV • PCM • Engine oil solenoid valve • Exhaust CMP sensor • Ignition coil/ion sensor No.1 • Ignition coil/ion sensor No.2 • Ignition coil/ion sensor No.3 • Ignition coil/ion sensor No.4
ENGINE3	<ul style="list-style-type: none"> • Cooling fan relay No.1 • Cooling fan relay No.2 • Cooling fan relay No.3

*1 : With i-stop system