

## COMPRESSOR BYPASS SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2]

id0113z7265500


### Resistance inspection

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
2. Remove the compressor bypass solenoid valve. (See COMPRESSOR BYPASS SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
3. Measure the resistance between the compressor bypass solenoid valve terminals A and B.

### Compressor bypass solenoid valve resistance (specification)

**30—34 ohms [20 °C {68 °F}]**

- If not within the specification, replace the compressor bypass solenoid valve. (See COMPRESSOR BYPASS SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)



ac5jjw00003470