

## PRIMARY SHAFT COMPONENT PREINSPECTION

id051500175600

### 5th Gear Thrust Clearance Inspection

1. Measure the 5th gear thrust clearance using the following procedure:

- (1) Secure the primary shaft component using a vice.

#### Caution


- Insert a protective plate between the vise and the part so as not to damage the part.

- (2) Set the dial gauge to the position of the arrow shown in the figure.
- (3) Move the 5th gear in the axial direction and measure the 5th gear thrust clearance.
  - If it exceeds the maximum specification, inspect the 5th gear and surrounding parts for damage and wear and replace the malfunctioning part.

#### 5th gear thrust clearance

**Specification: 0.227 mm {0.00894 in}**

**Maximum: 0.303 mm {0.0119 in}**



bd62zm00000037

### 6th Gear Thrust Clearance Inspection

1. Measure the 6th gear thrust clearance using the following procedure:

- (1) Secure the primary shaft component using a vise.

#### Caution


- Insert a protective plate between the vise and the part so as not to damage the part.

- (2) Set the dial gauge to the position of the arrow shown in the figure.
- (3) Move the 6th gear in the axial direction and measure the 6th gear thrust clearance.
  - If it exceeds the maximum specification, inspect the 6th gear and surrounding parts for damage and wear and replace the malfunctioning part.

#### 6th gear thrust clearance

**Specification: 0.208 mm {0.00819 in}**

**Maximum: 0.299 mm {0.0118 in}**



bd62zm00000038