




DTC P0335:00	CKP sensor circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> There is no CKP sensor signal input while the exhaust camshaft rotates 5 times. CKP sensor input signal pattern, received while crankshaft rotates 10 times, is incorrect. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Stops the fuel injection. Stops the ignition.
POSSIBLE CAUSE	<ul style="list-style-type: none"> CKP sensor connector or terminals malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> CKP sensor terminal A—PCM terminal 1BN CKP sensor terminal C—PCM terminal 1AD PCM connector or terminals malfunction Short to power supply in wiring harness between CKP sensor terminal C and PCM terminal 1AD CKP sensor circuits are shorted to each other Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> CKP sensor terminal A—PCM terminal 1BN CKP sensor terminal C—PCM terminal 1AD CKP sensor terminal B—PCM terminal 1AH CKP sensor malfunction <ul style="list-style-type: none"> CKP sensor is dirty CKP sensor pulse wheel malfunction PCM malfunction



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT CKP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the CKP sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	INSPECT CKP SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the CKP sensor connector is disconnected. Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> CKP sensor terminal A CKP sensor terminal C Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 10.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	INSPECT CKP SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the CKP sensor and PCM connectors are disconnected. Switch the ignition ON (engine off or on). Measure the voltage at the CKP sensor terminal C (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.
7	INSPECT CKP SENSOR CIRCUITS FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> Verify that the CKP sensor and PCM connectors are disconnected. Switch the ignition to off. Inspect for continuity between CKP sensor terminals A, C and B (wiring harness-side). Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 10.
		No	Go to the next step.
8	INSPECT CKP SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the CKP sensor and PCM connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> CKP sensor terminal A—PCM terminal 1BN CKP sensor terminal C—PCM terminal 1AD CKP sensor terminal B—PCM terminal 1AH Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 10.

STEP	INSPECTION		ACTION
9	INSPECT CKP SENSOR • Inspect the CKP sensor. (See CRANKSHAFT POSITION (CKP) SENSOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction?	Yes	Replace the CKP sensor, then go to the next step. (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
10	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine. • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.