
NOISE OCCURS AT IDLE WHEN VEHICLE IS STOPPED IN ALL POSITIONS [FW6A-EL, FW6AX-EL]

J0050317102300

TROUBLESHOOTING ITEM	Noise occurs at idle when vehicle is stopped in all positions
DESCRIPTION	• Transaxle is noisy in all positions when vehicle idling.
POSSIBLE CAUSE	1. Engine control system malfunction 2. Automatic transaxle internal parts malfunction — Oil pump malfunction — Torque converter internal parts malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY IF MALFUNCTION CAUSE IS ENGINE CONTROL SYSTEM OR TORQUE CONVERTER • Inspect the engine condition. • Is there any malfunction?	Yes Go to the appropriate symptom troubleshooting. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [FW6A-EL].) (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [FW6AX-EL].)