





DTC U0028:87 [REAR VEHICLE MONITORING SYSTEM]

id0902z2886700

System malfunction location	Rear vehicle monitoring control module (LH) and (RH) communication error
Detection condition	<ul style="list-style-type: none"> • No communication between rear vehicle monitoring control modules (LH) and (RH) for 1 s or more.
Fail-safe	<ul style="list-style-type: none"> • Inhibits the rear vehicle monitoring system.
Possible cause	<ul style="list-style-type: none"> • Rear vehicle monitoring control module (LH) connector or terminal malfunction • Rear vehicle monitoring control module (RH) connector or terminal malfunction • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — Rear vehicle monitoring control module (LH) terminal L to rear vehicle monitoring control module (RH) terminal C — Rear vehicle monitoring control module (LH) terminal I to rear vehicle monitoring control module (RH) terminal A • Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> — Rear vehicle monitoring control module (LH) terminal L to rear vehicle monitoring control module (RH) terminal C — Rear vehicle monitoring control module (LH) terminal I to rear vehicle monitoring control module (RH) terminal A • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — Rear vehicle monitoring control module (LH) terminal L to rear vehicle monitoring control module (RH) terminal C — Rear vehicle monitoring control module (LH) terminal I to rear vehicle monitoring control module (RH) terminal A • Rear vehicle monitoring control module (LH) malfunction • Rear vehicle monitoring control module (RH) malfunction
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>REAR VEHICLE MONITORING CONTROL MODULE (LH)</p>  </div> <div style="text-align: center;"> <p>REAR VEHICLE MONITORING CONTROL MODULE (RH)</p>  </div> </div> <p style="text-align: center;">REAR VEHICLE MONITORING CONTROL MODULE (LH)/(RH) WIRING HARNESS-SIDE CONNECTOR</p>  	

Diagnostic Procedure

Step	Inspection	Action	
1	INSPECT REAR VEHICLE MONITORING CONTROL MODULE (LH) CONNECTOR <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) • (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Disconnect the rear vehicle monitoring control module (LH) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
2	INSPECT REAR VEHICLE MONITORING CONTROL MODULE (RH) CONNECTOR <ul style="list-style-type: none"> • Disconnect the rear vehicle monitoring control modules (RH) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
3	INSPECT FOR SHORT TO GROUND IN CAN COMMUNICATION CIRCUIT BETWEEN REAR VEHICLE MONITORING CONTROL MODULES (LH) AND (RH) <ul style="list-style-type: none"> • Verify that the rear vehicle monitoring control module (LH) and (RH) connectors are disconnected. • Inspect for continuity between the following terminals (vehicle wiring harness side) and body ground. <ul style="list-style-type: none"> — Rear vehicle monitoring control module (LH) terminal L — Rear vehicle monitoring control module (LH) terminal I • Is there continuity? 	Yes	Repair or replace the wiring harness which is shorted to ground, then go to Step 6.
		No	Go to the next step.

Step	Inspection	Action	
4	INSPECT FOR SHORT TO POWER SUPPLY IN CAN COMMUNICATION CIRCUIT BETWEEN REAR VEHICLE MONITORING CONTROL MODULES (LH) AND (RH) <ul style="list-style-type: none"> • Verify that the rear vehicle monitoring control module (LH) and (RH) connectors are disconnected. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Switch the ignition ON (engine off or on). • Measure the voltage at the following terminals (vehicle wiring harness side). <ul style="list-style-type: none"> — Rear vehicle monitoring control module (LH) terminal L — Rear vehicle monitoring control module (LH) terminal I • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness which is shorted to power supply, then go to Step 6.
5	INSPECT FOR OPEN CIRCUIT IN CAN COMMUNICATION CIRCUIT BETWEEN REAR VEHICLE MONITORING CONTROL MODULES (LH) AND (RH) <ul style="list-style-type: none"> • Verify that the rear vehicle monitoring control module (LH) and (RH) connectors are disconnected. • Switch the ignition to off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Inspect the wiring harness between the following terminals (vehicle wiring harness side) for continuity. <ul style="list-style-type: none"> — Rear vehicle monitoring control module (LH) terminal L to rear vehicle monitoring control module (RH) terminal C — Rear vehicle monitoring control module (LH) terminal I to rear vehicle monitoring control module (RH) terminal A • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness, then go to the next step.

Step	Inspection	Action
6	PERFORM DTC INSPECTION AND VERIFY REAR VEHICLE MONITORING CONTROL MODULE (LH) MALFUNCTION <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for 1.5 s or more. • Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].) • Is DTC U0028:87 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear vehicle monitoring control module (LH), then go to the next step. (See REAR VEHICLE MONITORING CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to Step 8.
7	PERFORM DTC INSPECTION AND VERIFY REAR VEHICLE MONITORING CONTROL MODULE (RH) MALFUNCTION <ul style="list-style-type: none"> • Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for 1.5 s or more. • Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].) • Is DTC U0028:87 displayed? 	Yes Replace the rear vehicle monitoring control module (RH), then go to the next step. (See REAR VEHICLE MONITORING CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR VEHICLE MONITORING SYSTEM].)
		No DTC troubleshooting completed.