

---

**ACTIVE COMMAND MODES TABLE [REAR VEHICLE MONITORING SYSTEM]**

id0902z2960900

Command name	Unit/Operation	Data contents	Output part name
Buzzer	Off/On	<ul style="list-style-type: none"><li>• Off: Rear vehicle monitoring warning alarm does not sound.</li><li>• On: Rear vehicle monitoring warning alarm sounds.</li></ul>	Rear vehicle monitoring warning alarm (instrument cluster)
WRN_IND_L	Off/On	<ul style="list-style-type: none"><li>• Off: Turns off the RVM warning indicator light (LH).</li><li>• On: Illuminates the RVM warning indicator light (LH).</li></ul>	RVM warning indicator light (LH)
WRN_IND_R	Off/On	<ul style="list-style-type: none"><li>• Off: Turns off the RVM warning indicator light (RH).</li><li>• On: Illuminates the RVM warning indicator light (RH).</li></ul>	RVM warning indicator light (RH)