

# DTC P0102:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4700900

DTC P0102:00	MAF sensor circuit low input																																																														
DETECTION CONDITION	<ul style="list-style-type: none"><li>The PCM monitors input voltage from the MAF sensor when the engine is running. If the input voltage at the PCM terminal 2BC is <b>below 0.2 V for 5 s</b>, the PCM determines that the MAF sensor circuit has a malfunction.</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>This is a continuous monitor (CCM).</li><li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li><li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li><li>DTC is stored in the PCM memory.</li></ul>																																																														
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"><li>Restricts the upper limit of the engine speed.</li><li>Inhibits the evaporative purge control.</li></ul>																																																														
POSSIBLE CAUSE	<ul style="list-style-type: none"><li>MAF sensor/IAT sensor No.1 connector or terminals malfunction</li><li>Short to ground or open circuit in MAF sensor power supply circuit<ul style="list-style-type: none"><li>Short to ground in wiring harness between ENGINE1 15 A fuse and MAF sensor/IAT sensor No.1 terminal E</li><li>ENGINE1 15 A fuse malfunction</li><li>Open circuit in wiring harness between main relay terminal C and MAF sensor/IAT sensor No.1 terminal E</li></ul></li><li>Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none"><li>MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2BB</li><li>MAF sensor/IAT sensor No.1 terminal C—PCM terminal 2BC</li></ul></li><li>PCM connector or terminals malfunction</li><li>MAF sensor signal circuit and ground circuit are shorted to each other</li><li>Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none"><li>MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2BB</li><li>MAF sensor/IAT sensor No.1 terminal C—PCM terminal 2BC</li></ul></li><li>MAF sensor malfunction</li><li>PCM malfunction</li></ul>																																																														
<div><div><div><div><div>⑨</div><div>MAF SENSOR (MAF SENSOR/IAT SENSOR NO.1)</div><div></div></div><div><div>MAF SENSOR/IAT SENSOR NO.1 WIRING HARNESS-SIDE CONNECTOR</div><div></div></div><div><div><div>MAIN RELAY TERMINAL C</div><div>ENGINE1 15 A</div><div>PCM</div><div></div></div><div><div>PCM WIRING HARNESS-SIDE CONNECTOR</div><div><table><tr><td>2BE</td><td>2AZ</td><td>2AU</td><td>2AP</td><td>2AK</td></tr><tr><td>2BF</td><td>2BA</td><td>2AV</td><td>2AQ</td><td>2AL</td></tr><tr><td>2BG</td><td>2BB</td><td>2AW</td><td>2AR</td><td>2AM</td></tr><tr><td>2BH</td><td>2BC</td><td>2AX</td><td>2AS</td><td>2AN</td></tr><tr><td>2BD</td><td>2AY</td><td>2AT</td><td>2AO</td><td></td></tr></table><table><tr><td>2AE</td><td>2AA</td><td>2W</td><td>2S</td><td>2O</td><td>2K</td><td>2G</td><td>2C</td></tr><tr><td>2AF</td><td>2AB</td><td>2X</td><td>2T</td><td>2P</td><td>2L</td><td>2H</td><td>2D</td></tr></table><table><tr><td>2AI</td><td>2AG</td><td>2AC</td><td>2Y</td><td>2U</td><td>2Q</td><td>2M</td><td>2I</td><td>2E</td><td>2A</td></tr><tr><td>2AJ</td><td>2AH</td><td>2AD</td><td>2Z</td><td>2V</td><td>2R</td><td>2N</td><td>2J</td><td>2F</td><td>2B</td></tr></table></div></div></div></div></div></div>			2BE	2AZ	2AU	2AP	2AK	2BF	2BA	2AV	2AQ	2AL	2BG	2BB	2AW	2AR	2AM	2BH	2BC	2AX	2AS	2AN	2BD	2AY	2AT	2AO		2AE	2AA	2W	2S	2O	2K	2G	2C	2AF	2AB	2X	2T	2P	2L	2H	2D	2AI	2AG	2AC	2Y	2U	2Q	2M	2I	2E	2A	2AJ	2AH	2AD	2Z	2V	2R	2N	2J	2F	2B
2BE	2AZ	2AU	2AP	2AK																																																											
2BF	2BA	2AV	2AQ	2AL																																																											
2BG	2BB	2AW	2AR	2AM																																																											
2BH	2BC	2AX	2AS	2AN																																																											
2BD	2AY	2AT	2AO																																																												
2AE	2AA	2W	2S	2O	2K	2G	2C																																																								
2AF	2AB	2X	2T	2P	2L	2H	2D																																																								
2AI	2AG	2AC	2Y	2U	2Q	2M	2I	2E	2A																																																						
2AJ	2AH	2AD	2Z	2V	2R	2N	2J	2F	2B																																																						

## Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT MAF SENSOR/IAT SENSOR NO.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the MAF sensor/IAT sensor No.1 connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	<b>INSPECT MAF SENSOR POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>Switch the ignition ON (engine off).</li> <li>Measure the voltage at the MAF sensor/IAT sensor No.1 terminal E (wiring harness-side).</li> <li>Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the ENGINE1 15 A fuse. • If the fuse is blown: — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: — Replace the fuse. • If the fuse is normal: — Repair or replace the wiring harness for a possible open circuit. Go to Step 10.
5	<b>INSPECT MAF SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>Switch the ignition off.</li> <li>Inspect for continuity between the following terminals (wiring harness-side) and body ground:               <ul style="list-style-type: none"> <li>MAF sensor/IAT sensor No.1 terminal D</li> <li>MAF sensor/IAT sensor No.1 terminal C</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to Step 10.
		No	Go to the next step.
6	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
7	<b>INSPECT MAF SENSOR SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 and PCM connectors are disconnected.</li> <li>Inspect for continuity between MAF sensor/IAT sensor No.1 terminals C and B (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 10.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
8	<b>INSPECT MAF SENSOR CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the MAF sensor/IAT sensor No.1 and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2BB</li> <li>— MAF sensor/IAT sensor No.1 terminal C—PCM terminal 2BC</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or the replace the wiring harness for a possible open circuit, then go to Step 10.
9	<b>INSPECT MAF SENSOR</b> <ul style="list-style-type: none"> <li>• Inspect the MAF sensor. (See MASS AIR FLOW (MAF) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the MAF sensor/IAT sensor No.1, then go to the next step. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
10	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Start the engine and warm it up completely.</li> <li>• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.
11	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.