

DTC U0423:68 [BLIND SPOT MONITORING (BSM)]

id0902i3018400

System malfunction location	Error signal received from instrument cluster
Detection condition	<ul style="list-style-type: none">• The BSM control module received an error signal from the instrument cluster.
Fail-safe	<ul style="list-style-type: none">• BSM is stopped.
Possible cause	<ul style="list-style-type: none">• DTCs are stored in the instrument cluster.• Instrument cluster malfunction• BSM control module malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	VERIFY INSTRUMENT CLUSTER DTCs <ul style="list-style-type: none">• Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].)• Is the DTC displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No Go to the next step.
2	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS INSTRUMENT CLUSTER <ul style="list-style-type: none">• Clear BSM control module DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].)• Perform the DTC inspection for the BSM control module using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].)• Is the DTC U0423:68 displayed?	Yes Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)
		No Go to Step 4.
3	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none">• Clear BSM control module DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].)• Perform the DTC inspection for the BSM control module using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].)• Is the DTC U0423:68 displayed?	Yes Repeat the inspection from Step 1. <ul style="list-style-type: none">• If the malfunction recurs, replace the BSM control module, then go to the next step. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
4	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BLIND SPOT MONITORING (BSM)].)
		No DTC troubleshooting completed.