

BLIND SPOT MONITORING (BSM) WARNING ALARM


id092200028100

Purpose

- The Blind Spot Monitoring (BSM) warning alarm warns the driver of a possible accident.

Function

- If the instrument cluster receives a warning sound request signal from the BSM control module (RH), it sounds the BSM warning alarm using the buzzer in the instrument cluster.
- The BSM warning alarm sound pattern is as follows:




ac5wzn00001433

Construction

- The BSM warning alarm sounds using the buzzer built into the instrument cluster.

Operation

- The instrument cluster receives (1) the warning sound request signal from the BSM control module (RH).
- The instrument cluster turns the transistor on (2) based on the warning sound request signal.
- When the transistor turns on, a ground circuit with the alarm is established and the alarm sounds (3).



ac5ijn00000806

Fail-safe

- Function not equipped.