
RVM WARNING INDICATOR LIGHT INSPECTION

id092200015400

Note

- The RVM warning indicator lights are integrated into the outer mirror glass.
- For the RVM warning indicator light inspection, refer to the outer mirror glass inspection. (See OUTER MIRROR GLASS INSPECTION.)