

## NO.4 i-stop FUNCTION DOES NOT OPERATE [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id1103a5000900

4	i-stop FUNCTION DOES NOT OPERATE
DESCRIPTION	<ul style="list-style-type: none"> <li>i-stop function does not operate when vehicle is stopped.</li> </ul>
POSSIBLE CAUSE	<p><b>False detection of conditions other than i-stop function operation.</b></p> <ul style="list-style-type: none"> <li>Falsely detects that driver does not intend to stop.               <ul style="list-style-type: none"> <li>False detection of brake pedal not depressed (ATX)                   <ul style="list-style-type: none"> <li>Brake switch No.1 malfunction</li> <li>Open circuit in wiring harness between brake switch terminal D and PCM terminal 2G</li> </ul> </li> <li>Brake fluid pressure sensor (built-into DSC HU/CM) malfunction (i-stop indicator light (green) flashes)</li> </ul> </li> <li>Falsely detection of external vehicle temperature out of operation range (<b>-10 to 50 °C {14 to 122 °F}</b>)               <ul style="list-style-type: none"> <li>Ambient temperature sensor malfunction (sensor specific malfunction)</li> <li>Short or open circuit in wiring harness between ambient temperature sensor terminal A and PCM terminal 2I</li> <li>Open circuit in wiring harness between ambient temperature sensor terminal B and PCM terminal 2AJ</li> </ul> </li> <li>Climate control unit falsely detects that internal vehicle temperature is high. (with full-auto air conditioner)               <ul style="list-style-type: none"> <li>Cabin temperature sensor malfunction (sensor specific or motor malfunction)</li> <li>Short or open circuit in wiring harness between cabin temperature sensor terminal A and climate control unit terminal 1J</li> <li>Open circuit in wiring harness between cabin temperature sensor terminal B and climate control unit terminal 1X</li> </ul> </li> <li>Falsely detects that climate control unit detects driver-side air mix door position at MAX HOT or MAX COLD (with full-auto air conditioner)               <ul style="list-style-type: none"> <li>Driver-side air mix actuator malfunction</li> <li>Driver-side air mix actuator position sensor malfunction</li> <li>Driver-side air mix door or linkage stuck</li> </ul> </li> <li>Climate control unit falsely detects that i-stop function is operating in manual defroster mode.               <ul style="list-style-type: none"> <li>Climate control unit (panel switch) malfunction</li> </ul> </li> <li>False detection of vehicle not being parked               <ul style="list-style-type: none"> <li>False detection of steering wheel rotation and rotation speed                   <ul style="list-style-type: none"> <li>Steering angle sensor initialization malfunction</li> <li>Steering angle sensor malfunction</li> </ul> </li> <li>Short or open circuit in wiring harness between steering angle sensor and start stop unit terminals 1U, 1T, 1W or 1S</li> </ul> </li> </ul>

4	<b>i-stop FUNCTION DOES NOT OPERATE</b>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• False detection of vehicle in unsafe condition               <ul style="list-style-type: none"> <li>— False detection of open bonnet                   <ul style="list-style-type: none"> <li>• Bonnet latch switch malfunction (stuck open)</li> <li>• Open circuit in wiring harness between bonnet latch switch terminal A and rear body control module (RBCM) terminal 3L</li> </ul> </li> <li>— False detection of open door and liftgate                   <ul style="list-style-type: none"> <li>• Door latch switch malfunction</li> <li>• Liftgate latch switch malfunction</li> <li>• Open circuit in wiring harness between door latch switch and rear body control module (RBCM)</li> <li>• Short to ground in wiring harness between liftgate latch switch and rear body control module (RBCM)</li> </ul> </li> <li>— False detection of unfastened driver seat belt                   <ul style="list-style-type: none"> <li>• Driver-side buckle switch malfunction</li> <li>• Short to ground in wiring harness between driver-side buckle switch terminal 4A and SAS control module terminal 2U</li> </ul> </li> <li>— False detection of inclination angle (false detection of <b>7 % or more</b>) (ATX)                   <ul style="list-style-type: none"> <li>• Low-G (XY) sensor (built-into SAS control module) malfunction (In this case, the SAS control module records DTCs C0061:29 and C0062:29.)</li> <li>• Low-G (XY) sensor (built-into SAS control module) initialization malfunction</li> </ul> </li> <li>— DC-DC converter system error (exceeds capacity of DC-DC converter output due to open or short circuit in wiring harness and after-market electrical part)</li> <li>— False detection of low power brake unit load                   <ul style="list-style-type: none"> <li>• Power brake unit vacuum sensor malfunction</li> <li>• Short or open circuit in wiring harness between power brake unit vacuum sensor terminal C and PCM terminal 2BG</li> <li>• Short or open circuit in wiring harness between power brake unit vacuum sensor terminal B and PCM terminal 2Q</li> <li>• Short or open circuit in wiring harness between power brake unit vacuum sensor terminal A and PCM terminal 2AH</li> <li>• Power brake unit malfunction (air tightness malfunction)</li> <li>• Malfunction in vacuum hose to power brake unit (damage, bad check valve)</li> </ul> </li> </ul> </li> <li><b>Falsely detects possible inability of engine to restart</b> <ul style="list-style-type: none"> <li>• False detection of low (<b>55 °C {131 °F} or less</b>) or high (<b>110 °C {230 °F} or more</b>) engine coolant temperature               <ul style="list-style-type: none"> <li>— ECT sensor malfunction (sensor specific malfunction)</li> </ul> </li> <li>• False detection of high intake air temperature (<b>100 °C {212 °F} or more</b>)               <ul style="list-style-type: none"> <li>— IAT sensor No.1 malfunction (sensor specific malfunction)</li> </ul> </li> <li>• False detection of low (<b>less than 0 °C {32 °F}</b>) or high (<b>70 °C {158 °F} or more</b>) battery fluid temperature</li> <li>• False detection of low (<b>20 °C {68 °F} or less</b>) or high (<b>120 °C {248 °F} or more</b>) ATF temperature (ATX)</li> </ul> </li> <li><b>Determines possible inability of engine to restart</b> <ul style="list-style-type: none"> <li>• Battery voltage decrease               <ul style="list-style-type: none"> <li>— Battery malfunction</li> <li>— Generator malfunction</li> <li>— Generator malfunction (part, system, control malfunction)</li> <li>— Large amount of vehicle power consumption/Large amount of back-up current</li> </ul> </li> <li>• Determination of jump-start possibility               <ul style="list-style-type: none"> <li>— Engine start using key with bonnet opened</li> </ul> </li> </ul> </li> </ul>

#### Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<b>VERIFY i-stop INDICATOR LIGHT (GREEN) CONDITION WHEN MALFUNCTION OCCURS</b>  <b>Note</b> <ul style="list-style-type: none"> <li>• If any of the following conditions is met, then go to the next step.               <ul style="list-style-type: none"> <li>— MTX</li> <li>— European (L.H.D. U.K.) specs.</li> </ul> </li> <li>• Is the i-stop indicator light (green) flashing?</li> </ul>	Yes	Perform the symptom troubleshooting "NO.3 i-stop INDICATOR LIGHT (GREEN) FLASHES". (See NO.3 i-stop INDICATOR LIGHT (GREEN) FLASHES [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
2	<b>DETERMINE IF MALFUNCTION CAUSE IS BATTERY VOLTAGE DECREASE OR OTHER</b> <ul style="list-style-type: none"> <li>Start the engine and warm it up completely.</li> <li>Idle the engine.</li> <li>Access the BATT_SOC PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is the BATT_SOC PID value <b>above 75 %</b>?</li> </ul>	Yes	Go to the next step.
		No	Recharge the battery (6-hour normal recharge at <b>10 A</b> recharge current). (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
3	<b>INSPECT INSUFFICIENT ADVANCED KEY BATTERY POWER FOR MALFUNCTION</b> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>The following test should be performed on the advanced keyless entry system. If not equipped, go to Step 3.</li> <li>Verify the condition of the KEY indicator light (green) in the instrument cluster while the advanced key is in the cabin.</li> <li>Is the KEY indicator light (green) flashing?</li> </ul>	Yes	Replace the advanced key battery.
		No	Go to the next step.
4	<b>INSPECT EFFECT OF NON-GENUINE ELECTRICAL ACCESSORY FOR CAUSE OF MALFUNCTION</b> <ul style="list-style-type: none"> <li>Remove any non-genuine electrical accessory.</li> <li>Verify the malfunction symptom.</li> <li>Does the i-stop function operate when the vehicle is stopped?</li> </ul>	Yes	The system is normal. <ul style="list-style-type: none"> <li>Explain to the customer that the i-stop function does not operate due to the effect of the non-genuine electrical accessory installed.</li> </ul>
		No	Go to the next step.
5	<b>VERIFY DTC</b> <ul style="list-style-type: none"> <li>Retrieve the PCM, TCM, front body control module (FBCM), rear body control module (RBCM), DSC HU/CM, SAS control module, instrument cluster and climate control unit DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FW6A-EL, FW6AX-EL].) (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) (See DTC INSPECTION.) (See DTC INSPECTION [INSTRUMENT CLUSTER].) (See DTC DISPLAY [FULL-AUTO AIR CONDITIONER].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FW6A-EL, FW6AX-EL].) (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].) (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].) (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) (See DTC TABLE.) (See DTC TABLE [INSTRUMENT CLUSTER].) (See DTC TABLE [FULL-AUTO AIR CONDITIONER].)
		No	Go to the next step.
6	<b>INSPECT BATTERY</b> <ul style="list-style-type: none"> <li>Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the battery. (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
7	<b>INSPECT GENERATOR</b> <ul style="list-style-type: none"> <li>Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the inspection results.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
8	<b>DETERMINE IF MALFUNCTION CAUSE IS APP SENSOR SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>Start the engine and drive the vehicle for <b>5 min.</b></li> <li>Idle the engine.</li> <li>Access the following PCM and TCM PIDs using the M-MDS: (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC SYSTEM PID/DATA MONITOR INSPECTION [FW6A-EL, FW6AX-EL].) <b>PCM PIDs:</b> <ul style="list-style-type: none"> <li>BATT_TEMP (0—70 °C {32—158 °F})</li> <li>ECT (55—110 °C {131—230 °F})</li> <li>IAT (less than 100 °C {212 °F})</li> </ul> </li> <li><b>TCM PID: (ATX)</b> <ul style="list-style-type: none"> <li>TFT (20—120 °C {68—248 °F})</li> </ul> </li> <li>Are the PID values out of the i-stop operation range?</li> </ul>	Yes	Inspect the related-PID sensor which is out of range and the wiring harness. • If there is any malfunction: — Repair or replace the malfunctioning part according to the inspection results.
		No	Go to the next step.
9	<b>DETERMINE IF MALFUNCTION CAUSE IS AMBIENT TEMPERATURE SENSOR SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>Switch the ignition ON (engine off).</li> <li>Compare the ambient temperature sensor on the LCD with the actual ambient temperature.</li> <li>Does the ambient temperature on the LCD correspond to the actual ambient temperature?</li> </ul>	Yes	ATX: • Go to Step 12. MTX: • Go to Step 13.
		No	Go to the next step.
10	<b>INSPECT AMBIENT TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the ambient temperature sensor. (See AMBIENT TEMPERATURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the ambient temperature sensor. (See AMBIENT TEMPERATURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].)
		No	Go to the next step.
11	<b>INSPECT AMBIENT TEMPERATURE SENSOR CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Inspect for an open or short circuit between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>Ambient temperature sensor terminal A—PCM terminal 2I</li> <li>Ambient temperature sensor terminal B—PCM terminal 2AJ</li> </ul> </li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the suspected wiring harness.
		No	Replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
12	<b>VERIFY IF MALFUNCTION CAUSE IS STEERING ANGLE SENSOR INITIALIZATION NOT PERFORMED</b> <ul style="list-style-type: none"> <li>Drive the vehicle and verify the steering learning.</li> <li>Can learning be completed?</li> </ul>	Yes	Malfunction caused by the steering angle sensor initialization malfunction. • Investigate when there is a malfunction in steering angle learning.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
13*	<b>DETERMINE IF MALFUNCTION CAUSE IS DOOR LATCH SWITCH AND LIFTGATE LATCH SWITCH SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>• Switch the ignition ON (engine off).</li> <li>• Access the following rear body control module (RBCM) PIDs using the M-MDS: (See PID/DATA MONITOR INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) — TRUNK — DOOR_D — DOOR_ALL</li> <li>• Are the PID values congruent with the opening and closing of the doors and liftgate? (See PID/DATA MONITOR TABLE [REAR BODY CONTROL MODULE (RBCM)].)</li> </ul>	Yes	Go to Step 15.
		No	Go to the next step.
14	<b>INSPECT DOOR LATCH SWITCH AND LIFTGATE LATCH SWITCH</b> <ul style="list-style-type: none"> <li>• Inspect the PID-related switch in which the malfunction occurred in Step 13. (See LIFTGATE LATCH SWITCH INSPECTION.) (See FRONT DOOR LATCH SWITCH INSPECTION.) (See REAR DOOR LATCH SWITCH INSPECTION.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the applicable switch. (See LIFTGATE LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.) (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.) (See REAR DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.)
		No	Inspect the following wiring harness in which the malfunction occurred in Step 13: <ul style="list-style-type: none"> <li>• Open circuit in wiring harness between door latch switch and rear body control module (RBCM)</li> <li>• Short to ground in wiring harness between liftgate latch switch and rear body control module (RBCM) <ul style="list-style-type: none"> <li>— If there is any malfunction: <ul style="list-style-type: none"> <li>• Repair or replace the suspected wiring harness.</li> </ul> </li> </ul> </li></ul>
15	<b>DETERMINE IF MALFUNCTION CAUSE IS DRIVER-SIDE BUCKLE SWITCH SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>• Switch the ignition ON (engine off).</li> <li>• Access the SAS control module PID SEAT_B_D using the M-MDS. (See PID/DATA MONITOR INSPECTION.)</li> <li>• Is the SEAT_B_D PID value congruent with the seat belt condition? (See PID/DATA MONITOR TABLE.)</li> </ul>	Yes	With manual air conditioner: <ul style="list-style-type: none"> <li>• Go to Step 19.</li> </ul> With full-auto air conditioner: <ul style="list-style-type: none"> <li>• Go to Step 17.</li> </ul>
		No	Go to the next step.
16	<b>INSPECT DRIVER-SIDE BUCKLE SWITCH</b> <ul style="list-style-type: none"> <li>• Inspect the driver-side buckle switch. (See BUCKLE SWITCH INSPECTION.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the driver-side buckle switch. (See FRONT BUCKLE REMOVAL/INSTALLATION.)
		No	Repair or replace the wiring harness between driver-side buckle switch terminal 4A and SAS control module terminal 2U for a possible short to ground.
17	<b>DETERMINE IF MALFUNCTION CAUSE IS CABIN TEMPERATURE SENSOR SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>• Access the climate control unit PID INC_TMP_SEN using the M-MDS. (See PID/DATA MONITOR DISPLAY [FULL-AUTO AIR CONDITIONER].)</li> <li>• Does the INC_TMP_SEN PID value indicate the actual cabin temperature of the vehicle?</li> </ul>	Yes	Go to Step 19.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
18	<b>INSPECT CABIN TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the cabin temperature sensor. (See CABIN TEMPERATURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the cabin temperature sensor. (See CABIN TEMPERATURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].)
		No	Inspect the wiring harness between the following terminals for a short or open circuit: <ul style="list-style-type: none"> <li>Cabin temperature sensor terminal A—Climate control unit terminal 1J</li> <li>Cabin temperature sensor terminal B—Climate control unit terminal 1X</li> <li>— If there is any malfunction:               <ul style="list-style-type: none"> <li>Repair or replace the suspected wiring harness.</li> </ul> </li> </ul>
19*	<b>DETERMINE IF MALFUNCTION CAUSE IS BONNET LATCH SWITCH SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>Switch the ignition ON (engine off).</li> <li>Access the rear body control module (RBCM) PID HOOD using the M-MDS. (See PID/DATA MONITOR INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)</li> <li>Is the HOOD PID value normal? (See PID/DATA MONITOR TABLE [REAR BODY CONTROL MODULE (RBCM)].)</li> </ul>	Yes	Go to Step 21.
		No	Go to the next step.
20	<b>INSPECT BONNET LATCH SWITCH</b> <ul style="list-style-type: none"> <li>Inspect the bonnet latch switch. (See BONNET LATCH SWITCH INSPECTION.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the bonnet latch switch. (See BONNET LATCH AND RELEASE LEVER REMOVAL/INSTALLATION.)
		No	Repair or replace the wiring harness between bonnet latch switch terminal A and rear body control module (RBCM) terminal 3L for a possible open circuit.
21	<b>DETERMINE IF MALFUNCTION IS CAUSED BY STEERING ANGLE (ESTIMATED ABSOLUTE ANGLE) SIGNAL ERROR</b> <ul style="list-style-type: none"> <li>Start the engine and idle it.</li> <li>Using the M-MDS, display EPS control module PID STR_ANG. (See .ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS)</li> <li>Are the monitoring values normal?</li> </ul>	Yes	ATX: <ul style="list-style-type: none"> <li>Go to Step 23.</li> </ul> MTX: <ul style="list-style-type: none"> <li>Go to Step 25.</li> </ul>
		No	Go to the next step.
22	<b>INSPECT EPS CONTROL MODULE FOR MALFUNCTION</b> <ul style="list-style-type: none"> <li>Inspect the EPS control module. (See EPS CONTROL MODULE INSPECTION.)</li> <li>Is the EPS control module normal?</li> </ul>	Yes	Perform the following procedure: <ol style="list-style-type: none"> <li>Switch the ignition off, and after <b>2 min or more</b> have elapsed, switch the ignition ON.</li> <li>Start the engine and drive the vehicle <b>10 m {33 ft} or more</b> in a straight line at a speed of <b>10 km/h {6.2 mph} or more</b>.</li> <li>Stop the vehicle with the wheels in the straight-ahead position.</li> <li>Using the M-MDS, display EPS control module PID STR_ANG.               <ul style="list-style-type: none"> <li>If the STR_ANG value is normal, go to Step 31. (Because the steering angle (estimated absolute angle) has returned to normal)</li> <li>If the STR_ANG value is not normal, replace the EPS control module, then go to Step 31. (See STEERING WHEEL AND COLUMN REMOVAL/INSTALLATION.)</li> </ul> </li> </ol>
		No	Replace the EPS control module, then go to Step 31. (See STEERING WHEEL AND COLUMN REMOVAL/INSTALLATION.)

STEP	INSPECTION	RESULTS	ACTION
23	<b>DETERMINE IF MALFUNCTION CAUSED BY BRAKE OPERATION SIGNAL ERROR</b> <ul style="list-style-type: none"> <li>Switch the ignition ON (engine off).</li> <li>Access the PCM PID BOO using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Does the BOO PID value change according to the brake pedal operation? (See PCM INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul>	Yes	Go to Step 25.
		No	Go to the next step.
24	<b>INSPECT BRAKE SWITCH</b> <ul style="list-style-type: none"> <li>Inspect the brake switch. (See BRAKE SWITCH INSPECTION.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the brake switch. (See BRAKE PEDAL REMOVAL/INSTALLATION [L.H.D.].) (See BRAKE PEDAL REMOVAL/INSTALLATION [R.H.D.].)
		No	Open circuit in wiring harness between brake switch terminal D and PCM terminal 2G. • If there is any malfunction: — Repair or replace the suspected wiring harness.
25	<b>DETERMINE IF MALFUNCTION CAUSE IS POWER BRAKE UNIT VACUUM SENSOR SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>Start the engine and run it is idling.</li> <li>Access the PCM PID BBP using the M-MDS with the brake pedal held depressed while the i-stop function is operating. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Does the BBP PID value remain <b>less than -43 kPa {-0.44 kgf/cm<sup>2</sup>, -6.2 psi}</b>?</li> </ul>	Yes	With manual air conditioner: • Go to Step 31. With full-auto air conditioner: • Go to Step 29.
		No	Go to the next step.
26	<b>INSPECT POWER BRAKE UNIT VACUUM SENSOR FOR AIR TIGHTNESS MALFUNCTION</b> <ul style="list-style-type: none"> <li>Perform the vacuum function inspection for the power brake unit and the vacuum loss inspection. (See POWER BRAKE UNIT INSPECTION.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the inspection results.
		No	Go to the next step.
27	<b>INSPECT POWER BRAKE UNIT VACUUM SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the power brake unit vacuum sensor. (See POWER BRAKE UNIT INSPECTION.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the power brake unit vacuum sensor. (See POWER BRAKE UNIT VACUUM SENSOR REMOVAL/INSTALLATION.)
		No	Go to the next step.
28	<b>INSPECT POWER BRAKE UNIT VACUUM SENSOR CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Inspect for an open or short circuit between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Power brake unit vacuum sensor terminal C—PCM terminal 2BG</li> <li>— Power brake unit vacuum sensor terminal B—PCM terminal 2Q</li> <li>— Power brake unit vacuum sensor terminal A—PCM terminal 2AH</li> </ul> </li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the suspected wiring harness.
		No	Replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)

STEP	INSPECTION	RESULTS	ACTION
29	<b>DETERMINE IF MALFUNCTION CAUSE IS DRIVER-SIDE AIR MIX ACTUATOR SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>• Measure the voltage at the climate control unit terminal 1N (wiring harness-side) when the driver-side temperature setting is MAX HOT and MAX COLD.</li> <li>• Is the voltage normal? (See CLIMATE CONTROL UNIT INSPECTION [FULL-AUTO AIR CONDITIONER].)</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction is not resolved, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to Step 31.
		No	Go to the next step.
30	<b>INSPECT DRIVER-SIDE AIR MIX ACTUATOR</b> <ul style="list-style-type: none"> <li>• Inspect the driver-side air mix actuator. (See AIR MIX ACTUATOR INSPECTION [FULL-AUTO AIR CONDITIONER].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the driver-side air mix actuator. (See AIR MIX ACTUATOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].)
		No	Inspect the air mix actuator and linkage for sticking. (See A/C UNIT DISASSEMBLY/ASSEMBLY.) <ul style="list-style-type: none"> <li>• If there is any malfunction:               <ul style="list-style-type: none"> <li>— Repair or replace the malfunctioning part according to the inspection results.</li> </ul> </li> </ul>
31	Verify the test results. <ul style="list-style-type: none"> <li>• If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis.               <ul style="list-style-type: none"> <li>— If the vehicle is repaired, troubleshooting is completed.</li> <li>— If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> </li> </ul>		