



DTC P0117:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4701600

DTC P0117:00	ECT sensor circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the ECT sensor signal. If the PCM detects that the ECT sensor voltage at the PCM terminal 1AK is below 0.2 V for 5 s, the PCM determines that the ECT sensor circuit has a malfunction. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (engine cooling system). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Fixes water temperature for the engine control at 40 °C {104 °F}, and for the idle air control at 80 °C {176 °F} Operates the cooling fan (high speed rotation). Inhibits the fuel cut control during shift change.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Engine overheating (cooling system malfunction) ECT sensor connector or terminals malfunction ECT sensor malfunction Short to ground in wiring harness between ECT sensor terminal A and PCM terminal 1AK PCM connector or terminals malfunction ECT sensor signal circuit and ground circuit are shorted to each other PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<p>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED</p> <ul style="list-style-type: none"> Have the FREEZE FRAME DATA (Mode 2)/ snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (engine cooling system related) been recorded? 	<p>Yes: Go to the next step.</p> <p>No: Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step.</p>

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	VERIFY ENGINE CONDITION <ul style="list-style-type: none"> Verify the engine condition. Is the engine overheating? 	Yes	Perform the symptom troubleshooting "NO.17 COOLING SYSTEM CONCERNS-OVERHEATING". (See NO.17 COOLING SYSTEM CONCERNS-OVERHEATING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
4	INSPECT ECT SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the ECT sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	DETERMINE IF ECT SENSOR OR WIRING HARNESS MALFUNCTION <ul style="list-style-type: none"> Reconnect all disconnected connectors. Access the ECT PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Verify the ECT PID value when disconnecting the ECT sensor connector. Does the ECT PID value change? 	Yes	Replace the ECT sensor, then go to Step 9. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
6	INSPECT ECT SENSOR SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the ECT sensor connector is disconnected. Switch the ignition off. Inspect for continuity between ECT sensor terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to Step 9.
		No	Go to the next step.
7	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
8	INSPECT ECT SENSOR SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> Verify that the ECT sensor and PCM connectors are disconnected. Inspect for continuity between ECT sensor terminals A and B (wiring harness-side). Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to the next step.
		No	Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
10	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.