

DTC P0560:16 [START STOP UNIT]

id0902p6021900

System malfunction location	Start stop unit power supply voltage (+B3) low input
Detection condition	• Start stop unit power supply circuit (+B3) voltage of less than 8.5 V is detected for 5 s or more .
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> • Battery malfunction • Start stop unit connector or terminal malfunction • Start stop unit power supply circuit (+B3) malfunction <ul style="list-style-type: none"> — Short to ground in wiring harness between MAIN 200 A fuse and start stop unit terminal 2X — MAIN 200 A fuse malfunction — CABIN.+B 50 A fuse malfunction — SRS2/ESCL 15 A fuse malfunction — Open circuit in wiring harness between battery positive terminal and start stop unit terminal 2X • Start stop unit malfunction

Diagnostic Procedure

Diagnostic Procedure			
Step	Inspection	Action	
1	INSPECT BATTERY <ul style="list-style-type: none">• Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY INSPECTION [SKYACTIV-D 2.2].)• Is the battery normal?	Yes	Go to the next step.
		No	Recharge or replace the battery, then go to Step 4. (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY RECHARGING [SKYACTIV-D 2.2].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)

Step	Inspection	Action	
2	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Disconnect the start stop unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 4.
3	INSPECT START STOP UNIT POWER SUPPLY CIRCUIT (+B3) <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Display PID VPWR_B3 using the M-MDS. (See PID/DATA MONITOR INSPECTION [START STOP UNIT].) Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the MAIN 200 A, CABIN.+B 50 A and SRS2/ESCL 15 A fuses. <ul style="list-style-type: none"> If a fuse is burnt out: <ul style="list-style-type: none"> Repair or replace the wiring harness which is shorted to ground. Replace the burnt out fuse. If a fuse is damaged: <ul style="list-style-type: none"> Replace the damaged fuse. If the fuse is normal: <ul style="list-style-type: none"> Repair or replace the wiring harness which has an open circuit. Go to the next step.
4	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) Switch the ignition ON (engine off or on) and wait for 5 s or more. Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) Is DTC P0560:16 displayed? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.

Step	Inspection		Action
5	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	DTC troubleshooting completed.