


## OIL JET VALVE INSPECTION

id011000505900

1. Apply compressed air to oil jet valve A and verify that air passes through oil jet valve B.
  - If air does not flow, replace the oil jet valve.
  - If there is air flow with air compressor of less than **190 kPa {1.94 kgf/cm<sup>2</sup>, 27.6 psi}**, replace the oil jet valve.

### Oil jet valve opening pressure

**190—210 kPa {1.94—2.14 kgf/cm<sup>2</sup>, 27.6—30.4 psi}**



bes2ze00000107