

DTC P0629:00	Fuel pump control module circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> Over-current is detected. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Stops the fuel pump control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Fuel pump unit connector or terminals malfunction Fuel pump unit malfunction Fuel pump control module connector or terminals malfunction Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> Fuel pump unit terminal A—Fuel pump control module terminal 2C Fuel pump unit terminal B—Fuel pump control module terminal 2D Fuel pump control module malfunction PCM malfunction

FUEL PUMP UNIT
WIRING HARNESS-SIDE CONNECTOR

**FUEL PUMP RELAY
TERMINAL C**

FUEL PUMP CONTROL MODULE
WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.

STEP	INSPECTION	ACTION	
3	INSPECT FUEL PUMP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the fuel pump unit connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT FUEL PUMP UNIT <ul style="list-style-type: none"> • Inspect the fuel pump unit. (See FUEL PUMP UNIT INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the fuel pump unit, then go to Step 8. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
5	INSPECT FUEL PUMP CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the fuel pump control module connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	INSPECT FUEL PUMP UNIT CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the fuel pump unit and fuel pump control module connectors are disconnected. • Switch the ignition ON (engine off or on). • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Fuel pump unit terminal A — Fuel pump unit terminal B • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
7	INSPECT FUEL PUMP CONTROL MODULE <ul style="list-style-type: none"> • Inspect the fuel pump control module. (See FUEL PUMP CONTROL MODULE INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the fuel pump control module, then go to the next step. (See FUEL PUMP CONTROL MODULE REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.