

Caution

- Vehicle specifications differ depending on the vehicle identification number (VIN).

— Type A VIN:

JM0 KE***** 100001—

JM6 KE***** 100001—

JM8 KE***** 100001—

JMZ KE***** 100001—

— Type B VIN:

JM0 KE***** 200001—

JM6 KE***** 200001—

JM8 KE***** 200001—

JMZ KE***** 200001—

×: Applicable
—: Not applicable

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
B10A2:00 *10	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Vehicle collision	×	1	Other	C	×	(See DTC B10A2:00 [SKYACTIV-D 2.2].)
P0016:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Camshaft position/ Crankshaft position correlation problem	×	1	CCM	C, R	×	(See DTC P0016:00 [SKYACTIV-D 2.2].)
P0030:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor heater control circuit range/ performance problem	×	1	A/F sensor	C	×	(See DTC P0030:00 [SKYACTIV-D 2.2].)
P0034:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Compressor bypass solenoid valve control circuit low input	×	1	CCM	C, O, R	×	(See DTC P0034:00 [SKYACTIV-D 2.2].)
P0035:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Compressor bypass solenoid valve control circuit high input	×	1	CCM	C, O, R	×	(See DTC P0035:00 [SKYACTIV-D 2.2].)
P0047:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating solenoid valve control circuit low input	×	1	CCM	C, O, R	×	(See DTC P0047:00 [SKYACTIV-D 2.2].)
P0048:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating solenoid valve control circuit high input	×	1	CCM	C, O, R	×	(See DTC P0048:00 [SKYACTIV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P004C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Wastegate solenoid valve control circuit low input	×	1	CCM	C, O, R	×	(See DTC P004C:00 [SKYACT IV-D 2.2].)
P004D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Wastegate solenoid valve control circuit high input	×	1	CCM	C, O, R	×	(See DTC P004D:00 [SKYACT IV-D 2.2].)
P0072:00* 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Ambient temperature sensor circuit low input	—	1	Other	C, O, R	×	(See DTC P0072:00 [SKYACT IV-D 2.2].)
P0073:00* 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Ambient temperature sensor circuit high input	—	1	Other	C, O, R	×	(See DTC P0073:00 [SKYACT IV-D 2.2].)
P0079:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OCV circuit low input	×	1	CCM	C, O, R	×	(See DTC P0079:00 [SKYACT IV-D 2.2].)
P007B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Boost air temperature sensor circuit range/performance problem	×	2	CCM	C	×	(See DTC P007B:00 [SKYACT IV-D 2.2].)
P007C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Boost air temperature sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P007C:00 [SKYACT IV-D 2.2].)
P007D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Boost air temperature sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P007D:00 [SKYACT IV-D 2.2].)
P0080:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OCV control circuit high input	×	1	CCM	C, O, R	×	(See DTC P0080:00 [SKYACT IV-D 2.2].)
P0087:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Low pressure malfunction in common rail fuel pressure control system	×	2	Fuel system	C	×	(See DTC P0087:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0088:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	High pressure malfunction in common rail fuel pressure control system	×	2	Fuel system	C	×	(See DTC P0088:00 [SKYACT IV-D 2.2].)
P0089:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	High pressure malfunction in common rail fuel pressure control system	×	2	Fuel system	C	×	(See DTC P0089:00 [SKYACT IV-D 2.2].)
P0093:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel leakage from fuel pressure control system	×	1	Fuel system	C	×	(See DTC P0093:00 [SKYACT IV-D 2.2].)
P0096:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No. 2 circuit range/performance problem	×	2	CCM	C	×	(See DTC P0096:00 [SKYACT IV-D 2.2].)
P0097:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No. 2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0097:00 [SKYACT IV-D 2.2].)
P0098:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No. 2 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0098:00 [SKYACT IV-D 2.2].)
P009B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve signal circuit problem	×	1	Fuel system	C	×	(See DTC P009B:00 [SKYACT IV-D 2.2].)
P009F:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve malfunction (stuck close)	×	1	Fuel system	C	×	(See DTC P009F:00 [SKYACT IV-D 2.2].)
P0101:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAF sensor circuit range/performance problem	×	2	CCM	C	×	(See DTC P0101:00 [SKYACT IV-D 2.2].)
P0102:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAF sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0102:00 [SKYACT IV-D 2.2].)
P0103:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAF sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0103:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0106:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No.2 circuit range/performance problem	×	2	CCM	C	×	(See DTC P0106:00 [SKYACT IV-D 2.2].)
P0107:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No.2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0107:00 [SKYACT IV-D 2.2].)
P0108:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No.2 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0108:00 [SKYACT IV-D 2.2].)
P0111:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No. 1 circuit range/performance problem	×	2	CCM	C	×	(See DTC P0111:00 [SKYACT IV-D 2.2].)
P0112:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No. 1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0112:00 [SKYACT IV-D 2.2].)
P0113:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No. 1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0113:00 [SKYACT IV-D 2.2].)
P0116:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	ECT sensor circuit range/performance problem	×	2	CCM	C	×	(See DTC P0116:00 [SKYACT IV-D 2.2].)
P0117:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	ECT sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0117:00 [SKYACT IV-D 2.2].)
P0118:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	ECT sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0118:00 [SKYACT IV-D 2.2].)
P0121:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No.1/No.2 correlation problem	×	1	CCM	C	×	(See DTC P0121:00 [SKYACT IV-D 2.2].)
P0122:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No.1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0122:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0123:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No.1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0123:00 [SKYACT IV-D 2.2].)
P0131:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit low input	×	1	A/F sensor	C, O, R	×	(See DTC P0131:00 [SKYACT IV-D 2.2].)
P0132:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit high input	×	1	A/F sensor	C, O, R	×	(See DTC P0132:00 [SKYACT IV-D 2.2].)
P0133:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit no activity detected	×	1	A/F sensor	C	×	(See DTC P0133:00 [SKYACT IV-D 2.2].)
P0134:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit problem	×	1	A/F sensor	C, O, R	×	(See DTC P0134:00 [SKYACT IV-D 2.2].)
P0154:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Atmosphere learning malfunction in A/F sensor circuit	×	1	A/F sensor	C	×	(See DTC P0154:00 [SKYACT IV-D 2.2].)
P0181:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel temperature sensor circuit range/performance problem	×	2	Fuel system	C	×	(See DTC P0181:00 [SKYACT IV-D 2.2].)
P0182:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel temperature sensor circuit low input	×	1	Fuel system	C, O, R	×	(See DTC P0182:00 [SKYACT IV-D 2.2].)
P0183:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel temperature sensor circuit high input	×	1	Fuel system	C, O, R	×	(See DTC P0183:00 [SKYACT IV-D 2.2].)
P0191:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure sensor circuit range/performance problem	×	2	Fuel system	C	×	(See DTC P0191:00 [SKYACT IV-D 2.2].)
P0192:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure sensor circuit low input	×	1	Fuel system	C, O, R	×	(See DTC P0192:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0193:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure sensor circuit high input	×	1	Fuel system	C, O, R	×	(See DTC P0193:00 [SKYACT IV-D 2.2].)
P0196:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil temperature sensor circuit range/performance problem	×	2	CCM	C	×	(See DTC P0196:00 [SKYACT IV-D 2.2].)
P0197:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil temperature sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0197:00 [SKYACT IV-D 2.2].)
P0198:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil temperature sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0198:00 [SKYACT IV-D 2.2].)
P0201:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.1 circuit operating abnormally	×	1	Fuel system	C, R	×	(See DTC P0201:00 [SKYACT IV-D 2.2].)
P0202:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.2 circuit operating abnormally	×	1	Fuel system	C, R	×	(See DTC P0202:00 [SKYACT IV-D 2.2].)
P0203:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.3 circuit operating abnormally	×	1	Fuel system	C, R	×	(See DTC P0203:00 [SKYACT IV-D 2.2].)
P0204:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.4 circuit operating abnormally	×	1	Fuel system	C, R	×	(See DTC P0204:00 [SKYACT IV-D 2.2].)
P0219:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine overspeed condition	—	1	Other	C	×	(See DTC P0219:00 [SKYACT IV-D 2.2].)
P0222:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No.2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0222:00 [SKYACT IV-D 2.2].)
P0223:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No.2 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0223:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0234:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Small-type turbocharger overboost condition	×	2	CCM	C	×	(See DTC P0234:00 [SKYACT IV-D 2.2].)
P0236:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No.1 circuit range/performance problem	×	2	CCM	C	×	(See DTC P0236:00 [SKYACT IV-D 2.2].)
P0237:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No.1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0237:00 [SKYACT IV-D 2.2].)
P0238:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No.1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0238:00 [SKYACT IV-D 2.2].)
P0299:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Small-type turbocharger underboost condition	×	2	CCM	C	×	(See DTC P0299:00 [SKYACT IV-D 2.2].)
P02CA:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Large-type turbocharger overboost condition	×	2	CCM	C	×	(See DTC P02CA:00 [SKYACT IV-D 2.2].)
P02CB:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Large-type turbocharger underboost condition	×	2	CCM	C	×	(See DTC P02CB:00 [SKYACT IV-D 2.2].)
P0301:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.1 misfire detected	×	2	Misfire	C	×	(See DTC P0301:00, P0302:00, P0303:00, P0304:00 [SKYACT IV-D 2.2].)
P0302:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.2 misfire detected	×	2	Misfire	C	×	
P0303:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.3 misfire detected	×	2	Misfire	C	×	
P0304:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.4 misfire detected	×	2	Misfire	C	×	
P0313:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Misfire detected with low fuel	×	1	Other	C	×	(See DTC P0313:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0336:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CKP sensor circuit range/performance problem	×	2	CCM	C, R	×	(See DTC P0336:00 [SKYACT IV-D 2.2].)
P0337:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CKP sensor circuit problem	×	1	CCM	C, R	×	(See DTC P0337:00 [SKYACT IV-D 2.2].)
P0339:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CKP sensor circuit range/performance problem	×	1	CCM	C	×	(See DTC P0339:00 [SKYACT IV-D 2.2].)
P0341:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CMP sensor circuit range/performance problem	×	2	CCM	C, R	×	(See DTC P0341:00 [SKYACT IV-D 2.2].)
P0342:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CMP sensor circuit problem	×	1	CCM	C, R	×	(See DTC P0342:00 [SKYACT IV-D 2.2].)
P0383:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow control module circuit low input	×	1	CCM	C	×	(See DTC P0383:00 [SKYACT IV-D 2.2].)
P0384:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow control module circuit high input	×	1	CCM	C	×	(See DTC P0384:00 [SKYACT IV-D 2.2].)
P0401:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR flow insufficient detected	×	2	CCM	C	×	(See DTC P0401:00 [SKYACT IV-D 2.2].)
P0402:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR flow excessive detected	×	2	CCM	C	×	(See DTC P0402:00 [SKYACT IV-D 2.2].)
P0404:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Circuit malfunction in EGR valve DC motor control system	×	1	CCM	C	×	(See DTC P0404:00 [SKYACT IV-D 2.2].)
P0405:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR valve position sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0405:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0406:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR valve position sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0406:00 [SKYACT IV-D 2.2].)
P0421:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Warm up catalyst system efficiency below threshold	×	2	CCM	C	×	(See DTC P0421:00 [SKYACT IV-D 2.2].)
P0471:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.1 circuit range/performance problem	×	2	CCM	C	×	(See DTC P0471:00 [SKYACT IV-D 2.2].)
P0472:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0472:00 [SKYACT IV-D 2.2].)
P0473:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0473:00 [SKYACT IV-D 2.2].)
P0480:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Fan control module No.1 control circuit problem	—	1	Other	C, O	×	(See DTC P0480:00 [SKYACT IV-D 2.2].)
P0481:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Fan control module No.2 control circuit problem	—	1	Other	C, O	×	(See DTC P0481:00 [SKYACT IV-D 2.2].)
P0488:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Duty signal error in EGR valve (cooler side) control system	×	1	CCM	C	×	(See DTC P0488:00 [SKYACT IV-D 2.2].)
P0500:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	VSS circuit problem	×	1	CCM	C, O, R	×	(See DTC P0500:00 [SKYACT IV-D 2.2].)
P0522:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil pressure sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0522:00 [SKYACT IV-D 2.2].)
P0523:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil pressure sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0523:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0524:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil pressure too low	×	1	CCM	C	×	(See DTC P0524:00 [SKYACT IV-D 2.2].)
P0532:00* 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Refrigerant pressure sensor circuit low input	×	1	Other	C	×	(See DTC P0532:00 [SKYACT IV-D 2.2].)
P0533:00* 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Refrigerant pressure sensor circuit high input	×	1	Other	C	×	(See DTC P0533:00 [SKYACT IV-D 2.2].)
P053B:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Blow-by heater relay control circuit low input	—	1	Other	C, O, R	×	(See DTC P053B:00 [SKYACT IV-D 2.2].)
P053C:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Blow-by heater relay control circuit high input	—	1	Other	C, O, R	×	(See DTC P053C:00 [SKYACT IV-D 2.2].)
P0545:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.1 circuit low input	×	1	CCM	C	×	(See DTC P0545:00 [SKYACT IV-D 2.2].)
P0546:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0546:00 [SKYACT IV-D 2.2].)
P0555:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Power brake unit vacuum sensor circuit problem	×	1	Other	C, R	×	(See DTC P0555:00 [SKYACT IV-D 2.2].)
P055F:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil pressure control circuit low oil pressure	×	1	CCM	C	×	(See DTC P055F:00 [SKYACT IV-D 2.2].)
P0571:00	ON	ON	OFF	OFF	OFF	OFF	OFF	Brake switch circuit problem	×	2	CCM	C	×	(See DTC P0571:00 [SKYACT IV-D 2.2].)
P057F:00	OFF	ON	Flash	OFF	OFF	OFF	OFF	Power system: Battery deterioration	×	2	Other	C	×	(See DTC P057F:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P058A:00	OFF	ON	Flash	ON*6	OFF	OFF	OFF	Current sensor: Function malfunction	×	2	Other	C	×	(See DTC P058A:00 [SKYACT IV-D 2.2].)
P0601:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM memory check sum error	×	1	CCM	C, O, R	×	(See DTC P0601:00 [SKYACT IV-D 2.2].)
P0602:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM programming error	×	1	CCM	C	×	(See DTC P0602:00 [SKYACT IV-D 2.2].)
P0605:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM memory check sum error	×	1	CCM	C	×	(See DTC P0605:00 [SKYACT IV-D 2.2].)
P0606:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM processor error	×	1	CCM	C, O, R	×	(See DTC P0606:00 [SKYACT IV-D 2.2].)
P0607:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Control module performance problem	×	1	CCM	C, O, R	×	(See DTC P0607:00 [SKYACT IV-D 2.2].)
P0610:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM vehicle configuration error	×	1	CCM	C	×	(See DTC P0610:00 [SKYACT IV-D 2.2].)
P0615:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Starter relay circuit problem	—	1	Other	C	×	(See DTC P0615:00 [SKYACT IV-D 2.2].)
P062A:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Suction control valve circuit problem	×	1	Fuel system	C, R	×	(See DTC P062A:00 [SKYACT IV-D 2.2].)
P062B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM internal malfunction	×	1	Fuel system	C, R	×	(See DTC P062B:00 [SKYACT IV-D 2.2].)
P0642:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply circuit low input	×	1	CCM	C	×	(See DTC P0642:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0643:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply circuit high input	×	1	CCM	C	×	(See DTC P0643:00 [SKYACT IV-D 2.2].)
P0646:00* 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	A/C relay circuit low input	—	1	Other	C	×	(See DTC P0646:00 [SKYACT IV-D 2.2].)
P0647:00* 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	A/C relay circuit high input	—	1	Other	C	×	(See DTC P0647:00 [SKYACT IV-D 2.2].)
P0652:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply control circuit low input	×	1	CCM	C	×	(See DTC P0652:00 [SKYACT IV-D 2.2].)
P0653:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply control circuit high input	×	1	CCM	C	×	(See DTC P0653:00 [SKYACT IV-D 2.2].)
P0668:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM internal temperature sensor circuit low input	×	1	CCM	C	×	(See DTC P0668:00 [SKYACT IV-D 2.2].)
P0669:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM internal temperature sensor circuit high input	×	1	CCM	C	×	(See DTC P0669:00 [SKYACT IV-D 2.2].)
P0670:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow control module control circuit problem	×	1	CCM	C	×	(See DTC P0670:00 [SKYACT IV-D 2.2].)
P0671:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.1 control circuit problem	×	1	CCM	C	×	(See DTC P0671:00 [SKYACT IV-D 2.2].)
P0672:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.2 control circuit problem	×	1	CCM	C	×	(See DTC P0672:00 [SKYACT IV-D 2.2].)
P0673:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.3 control circuit problem	×	1	CCM	C	×	(See DTC P0673:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0674:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.4 control circuit problem	×	1	CCM	C	×	(See DTC P0674:00 [SKYACT IV-D 2.2].)
P0683:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow control module control circuit problem	×	1	CCM	C	×	(See DTC P0683:00 [SKYACT IV-D 2.2].)
P0684:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow control module control circuit communication error	×	1	CCM	C	×	(See DTC P0684:00 [SKYACT IV-D 2.2].)
P06B8:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Internal control module non-volatile RAM error	×	1	CCM	C, O, R	×	(See DTC P06B8:00 [SKYACT IV-D 2.2].)
P06DB:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil solenoid valve circuit low input	×	1	CCM	C, O, R	×	(See DTC P06DB:00 [SKYACT IV-D 2.2].)
P06DC:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil solenoid valve control circuit high input	×	1	CCM	C, O, R	×	(See DTC P06DC:00 [SKYACT IV-D 2.2].)
P06DD:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Engine oil pressure switch control circuit high input	—	1	Other	C	×	(See DTC P06DD:00 [SKYACT IV-D 2.2].)
P06DE:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Engine oil pressure switch control circuit low input	—	1	Other	C	×	(See DTC P06DE:00 [SKYACT IV-D 2.2].)
P0703:00	ON	ON	OFF	OFF	OFF	OFF	OFF	Brake switch input circuit problem	×	2	CCM	C	×	(See DTC P0703:00 [SKYACT IV-D 2.2].)
P0704:00* 3	ON	OFF	OFF	OFF	OFF	OFF	OFF	CPP switch input circuit problem	×	2	CCM	C	×	(See DTC P0704:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P07BE:00*3	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Transmission indeterminate failure (failed to neutral)	—	1	Other	C	×	(See DTC P07BE:00 [SKYACT IV-D 2.2].)
P0850:00*3	ON	OFF	OFF	OFF	OFF	OFF	OFF	Neutral switch No.1 input circuit problem	×	2	CCM	C	×	(See DTC P0850:00 [SKYACT IV-D 2.2].)
P0A0F:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Engine failed to restart	—	1	Other	C	×	(See DTC P0A0F:00 [SKYACT IV-D 2.2].)
P0A8D:00	OFF	ON	Flash	OFF	OFF	OFF	OFF	Power supply system circuit low input	×	1	Other	C	×	(See DTC P0A8D:00 [SKYACT IV-D 2.2].)
P0A94:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	DC-DC converter: control circuit signal error	×	1	Other	C	×	(See DTC P0A94:00 [SKYACT IV-D 2.2].)
P111A:00*10	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine coolant temperature is high	×	—	Other	C	×	(See DTC P111A:00 [SKYACT IV-D 2.2].)
P1140:00	OFF	ON	OFF	OFF	OFF	ON*7	OFF	Sedimentor switch control circuit range/performance problem	—	1	Other	C	×	(See DTC P1140:00 [SKYACT IV-D 2.2].)
P115A:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Lack of remaining fuel (output restriction)	×	1	Other	C	×	(See DTC P115A:00 [SKYACT IV-D 2.2].)
P115B:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Lack of remaining fuel (fuel injection pause)	×	1	Other	C	×	(See DTC P115B:00 [SKYACT IV-D 2.2].)
P117A:00*10	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Record of torque restriction for piston protection	—	—	Other	C	×	(See DTC P117A:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P1196:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Main relay control circuit problem	—	1	Other	C	×	(See DTC P1196:00 [SKYACT IV-D 2.2].)
P1200:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injection amount learning not completed	×	1	Other	C	×	(See DTC P1200:00 [SKYACT IV-D 2.2].)
P1260:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Immobilizer system problem	—	—	Other	C	—	(See DTC P1260:00 [SKYACT IV-D 2.2].)
P1282:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Common rail control system problem	×	2	Fuel system	C	×	(See DTC P1282:00 [SKYACT IV-D 2.2].)
P1303:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	EGR cooler bypass valve full closing angle malfunction	—	1	Other	C	×	(See DTC P1303:00 [SKYACT IV-D 2.2].)
P1329:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Common rail pressure higher than desired (engine running)	×	2	Fuel system	C	×	(See DTC P1329:00 [SKYACT IV-D 2.2].)
P1336:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	CKP sensor/ CMP sensor malfunction	—	1	CCM	C	×	(See DTC P1336:00 [SKYACT IV-D 2.2].)
P1378:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector circuit low input	×	1	Fuel system	C, R	×	(See DTC P1378:00 [SKYACT IV-D 2.2].)
P1379:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector circuit high input	×	1	Fuel system	C, R	×	(See DTC P1379:00 [SKYACT IV-D 2.2].)
P1589:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control duty signal error	—	2	CCM	C	×	(See DTC P1589:00 [SKYACT IV-D 2.2].)
P1675:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector code not programmed	×	1	Fuel system	C	×	(See DTC P1675:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P1676:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector code mistakenly programmed	×	1	Fuel system	C	×	(See DTC P1676:00 [SKYACT IV-D 2.2].)
P167B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injection amount learning not completed in fuel injection system	×	1	Other	C	×	(See DTC P167B:00 [SKYACT IV-D 2.2].)
P176E:00*3	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Clutch stroke sensor/starter interlock switch correlation problem	×	1	Other	C, O, R*1 1/ C*1 2	×	(See DTC P176E:00 [SKYACT IV-D 2.2].)
P1905:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Check connector circuit low input	—	1	Other	C	×	(See DTC P1905:00 [SKYACT IV-D 2.2].)
P2002:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Diesel particulate filter function decreased	×	2	CCM	C	×	(See DTC P2002:00 [SKYACT IV-D 2.2].)
P2032:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P2032:00 [SKYACT IV-D 2.2].)
P2033:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.2 circuit high input	×	1	CCM	C	×	(See DTC P2033:00 [SKYACT IV-D 2.2].)
P2101:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control circuit overcurrent	×	1	CCM	C	×	(See DTC P2101:00 [SKYACT IV-D 2.2].)
P2105:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Intake air shutter valve actuator control system malfunction (forced engine shutdown)	—	1	Other	C	×	(See DTC P2105:00 [SKYACT IV-D 2.2].)
P2118:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control duty signal error	×	2	CCM	C	×	(See DTC P2118:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2146:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.1 and No.4 circuit abnormal operation	×	1	Fuel system	C, R	×	(See DTC P2146:00 [SKYACT IV-D 2.2].)
P2147:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.1 and No.4 circuit low input	×	1	Fuel system	C, R	×	(See DTC P2147:00 [SKYACT IV-D 2.2].)
P2148:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.1 and No.4 circuit high input	×	1	Fuel system	C, R	×	(See DTC P2148:00 [SKYACT IV-D 2.2].)
P2149:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.2 and No.3 circuit abnormal operation	×	1	Fuel system	C, R	×	(See DTC P2149:00 [SKYACT IV-D 2.2].)
P2150:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.2 and No.3 circuit low input	×	1	Fuel system	C, R	×	(See DTC P2150:00 [SKYACT IV-D 2.2].)
P2151:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No.2 and No.3 circuit high input	×	1	Fuel system	C, R	×	(See DTC P2151:00 [SKYACT IV-D 2.2].)
P2227:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	BARO sensor circuit range/performance problem	×	2	CCM	C	×	(See DTC P2227:00 [SKYACT IV-D 2.2].)
P2228:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	BARO sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P2228:00 [SKYACT IV-D 2.2].)
P2229:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	BARO sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P2229:00 [SKYACT IV-D 2.2].)
P2263:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating valve control circuit range/performance problem	×	2	CCM	C	×	(See DTC P2263:00 [SKYACT IV-D 2.2].)
P2299:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Accelerator pedal: spring back malfunction	—	1	Other	C	×	(See DTC P2299:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P242C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.3 circuit low input	×	1	CCM	C, O, R	×	(See DTC P242C:00 [SKYACT IV-D 2.2].)
P242D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.3 circuit high input	×	1	CCM	C	×	(See DTC P242D:00 [SKYACT IV-D 2.2].)
P242F:00	ON	ON	OFF	OFF	OFF	OFF	Flash * 8	Diesel particulate filter excess accumulation (exceeded acceptable amount)	×	1	CCM	C	×	(See DTC P242F:00 [SKYACT IV-D 2.2].)
P244A:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.2 range/performance problem	×	1	Other	C	×	(See DTC P244A:00 [SKYACT IV-D 2.2].)
P2452:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Signal malfunction in exhaust gas pressure sensor No.2	—	1	Other	C	×	(See DTC P2452:00 [SKYACT IV-D 2.2].)
P2453:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Pressure malfunction in exhaust gas pressure sensor No.2	—	1	Other	C	×	(See DTC P2453:00 [SKYACT IV-D 2.2].)
P2454:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P2454:00 [SKYACT IV-D 2.2].)
P2455:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.2 circuit high input	×	1	CCM	C, O, R	×	(See DTC P2455:00 [SKYACT IV-D 2.2].)
P2456:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Characteristic malfunction in exhaust gas pressure sensor No.2	×	1	CCM	C	×	(See DTC P2456:00 [SKYACT IV-D 2.2].)
P2458:00	OFF	ON	OFF	OFF	OFF	OFF	Flash * 8	Diesel particulate filter excess accumulation (mid)	×	1	Other	C	×	(See DTC P2458:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P245A:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR cooler bypass valve control: Drive circuit malfunction	×	1	CCM	C	×	(See DTC P245A:00 [SKYACT IV-D 2.2].)
P245B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR cooler bypass valve control: duty signal malfunction	×	1	CCM	C	×	(See DTC P245B:00 [SKYACT IV-D 2.2].)
P2463:00	ON	ON	OFF	OFF	OFF	OFF	Flash* 8	Diesel particulate filter excess accumulation (large)	×	1	CCM	C	×	(See DTC P2463:00 [SKYACT IV-D 2.2].)
P246C:00	OFF	ON	OFF	OFF	ON*9	OFF	Flash* 8	Engine oil dilution, oil pressure decreased	—	1	Other	C	×	(See DTC P246C:00 [SKYACT IV-D 2.2].)
P2494:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR cooler bypass valve position sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P2494:00 [SKYACT IV-D 2.2].)
P2495:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR cooler bypass valve position sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P2495:00 [SKYACT IV-D 2.2].)
P24A5:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	EGR cooler bypass valve control: EGR cooler bypass valve (stuck)	×	2	CCM	C	×	(See DTC P24A5:00 [SKYACT IV-D 2.2].)
P2502:00	OFF	OFF	Flash	ON*6	OFF	OFF	OFF	Generator system: Malfunction in voltage generated by generator	×	1	Other	C	×	(See DTC P2502:00 [SKYACT IV-D 2.2].)
P2503:00	OFF	OFF	Flash	ON*6	OFF	OFF	OFF	Generator system: Voltage generated by generator is low	×	1	Other	C	×	(See DTC P2503:00 [SKYACT IV-D 2.2].)
P2504:00	OFF	OFF	Flash	ON*6	OFF	OFF	OFF	Generator system: Voltage generated by generator is high	×	1	Other	C	×	(See DTC P2504:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2507:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM battery voltage low input	×	1	CCM	C	×	(See DTC P2507:00 [SKYACT IV-D 2.2].)
P252F:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil level too high	—	1	Other	C	×	(See DTC P252F:00 [SKYACT IV-D 2.2].)
P253F:00	OFF	ON	OFF	OFF	ON*9	OFF	Flash [*] ₈	Engine oil deteriorated	—	1	Other	C	×	(See DTC P253F:00 [SKYACT IV-D 2.2].)
P2564:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating valve position sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P2564:00 [SKYACT IV-D 2.2].)
P2565:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating valve position sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P2565:00 [SKYACT IV-D 2.2].)
P2610:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Instrument cluster internal engine off timer performance problem	×	2	CCM	—	×	(See DTC P2610:00 [SKYACT IV-D 2.2].)
P2621:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve position sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P2621:00 [SKYACT IV-D 2.2].)
P2622:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve position sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P2622:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
U0073:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN system communication error (HS CAN)	—	1	Other	C, O, R	×	(See DTC U0073:00, U0101:00, U0121:00, U0131:00, U0140:00, U0151:00, U0155:00, U0214:00, U0235:00 [SKYACT IV-D 2.2].)
U0074:00 *4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN system communication error (local CAN between PCM and TCM)	—	1	Other	C, O, R	×	(See DTC U0074:00 [SKYACT IV-D 2.2].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
U0101:00 *4	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication : communication error to TCM	×	1	CCM	C, O, R	×	(See DTC U0073:00 , U0101:00 , U0121:00 , U0131:00 , U0140:00 , U0151:00 , U0155:00 , U0214:00 , U0235:00 [SKYACT IV-D 2.2].)
U0121:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication : communication error to DSC HU/CM	×	1	CCM	C, O, R	×	
U0131:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication : communication error to EPS control module	—	1	Other	C, O, R	×	
U0140:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication : communication error to front body control module (FBCM)	—	1	Other	C, O, R	×	
U0151:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication : communication error to SAS control module	—	1	Other	C, O, R	×	
U0155:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication : communication error to instrument cluster	×	1	CCM	C, O, R	×	
U0214:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN communication : communication error to start stop unit	—	1	Other	C, O, R	×	
U0235:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN communication : communication error to laser sensor	—	1	Other	C	×	

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
U0298:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN/LIN communication system: DC-DC converter information communication error with front body control module (FBCM)	×	1	Other	C	×	(See DTC U0298:00 [SKYACT IV-D 2.2].)
U0302:00 *4	ON	OFF	OFF	OFF	OFF	OFF	OFF	TCM processor error	×	1	CCM	C	×	(See DTC U0302:00 [SKYACT IV-D 2.2].)
U0315:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	DSC HU/CM error	—	1	Other	C	×	(See DTC U0315:00 [SKYACT IV-D 2.2].)
U0320:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	EPS control module error	—	1	Other	C, O, R	×	(See DTC U0320:00 [SKYACT IV-D 2.2].)
U0323:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Instrument cluster error	—	1	Other	C, O, R	×	(See DTC U0323:00 [SKYACT IV-D 2.2].)
U0336:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	SAS control module error	—	1	Other	C, O, R	×	(See DTC U0336:00 [SKYACT IV-D 2.2].)
U0338:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Start stop unit error	—	1	Other	C, O, R	×	(See DTC U0338:00 [SKYACT IV-D 2.2].)
U0433:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Abnormal message from rear body control module (RBCM)	—	1	Other	C	×	(See DTC U0433:00 [SKYACT IV-D 2.2].)
U2300:00	OFF	ON*5	OFF	OFF	OFF	OFF	OFF	Global central configuration error	—	1	Other	C	×	(See DTC U2300:00 [SKYACT IV-D 2.2].)
U3000:41	OFF	OFF	OFF	OFF	OFF	OFF	OFF	PCM processor error	—	1	Other	C	—	(See DTC U3000:41 [SKYACT IV-D 2.2].)

*1 : C: CMDTC self test, O: KOEO self test, R: KOER self test

*2 : With air conditioner

*3 : MTX

*4 : ATX

*5 : Message "Vehicle System Inspection Required" is frequently indicated in TFT LCD. (With TFT LCD)

*6 : Message "Charging System Inspection Required" is frequently indicated in TFT LCD. (With TFT LCD)

*7 : Message "Drain Water from Fuel Filter" is frequently indicated in TFT LCD. (With TFT LCD)

*8 : Message "DPF Inspection Required" is frequently indicated in TFT LCD. (With TFT LCD)

*9 : Message "Engine Oil Pressure Inspection Required" is frequently indicated in TFT LCD. (With TFT LCD)

*10 : If equipped

*11 : Type A VIN

*12 : Type B VIN