

ACTIVE COMMAND MODES TABLE [INSTRUMENT CLUSTER]

id0902e8960900

Simulation item	Unit/ Operation	Data contents	Output part name
ALARM	On/Off	<ul style="list-style-type: none"> • On: Warning alarm sounds. • Off: Warning alarm does not sound. 	Warning alarm (instrument cluster)
LCD_SEG	Off/On	Vehicles without TFT LCD display: <ul style="list-style-type: none"> • Off: Turns off the LCD. • On: Fully displays LCD. Vehicles with TFT LCD display: <ul style="list-style-type: none"> • Off: Turns off the LCD. • On: Illuminates the LCD. 	Vehicles without TFT LCD display: <ul style="list-style-type: none"> • LCD (instrument cluster) Vehicles with TFT LCD display: <ul style="list-style-type: none"> • TFT LCD display (instrument cluster)
SPEEDOMT R	Off/60 Km/h/ 120 Km/h	European (L.H.D./U.K.), General (L.H.D./R.H.D.) specs., Australian specs.: <ul style="list-style-type: none"> • Off: Moves speedometer needle to the bottom-most position. • 60 Km/h: Moves speedometer needle to 61—66 km/h {38—41 mph}. • 120 Km/h: Moves speedometer needle to 122—129 km/h {75.9—80.1 mph}. General (L.H.D./R.H.D.) specs.: <ul style="list-style-type: none"> • Off: Moves speedometer needle to the bottom-most position. • 60 Km/h: Moves speedometer needle to 58—62 km/h {36—39 mph}. • 120 Km/h: Moves speedometer needle to 117—123 km/h {72.8—76.4 mph}. 	Speedometer (instrument cluster)
TACHOMT R	Off/3000 RPM/6000 RPM	<ul style="list-style-type: none"> • Off: Moves tachometer needle to the bottom-most position. • 3000 RPM: Moves tachometer needle to approx. 3,050 rpm. • 6000 RPM: Moves tachometer needle to approx. 6,100 rpm. 	Tachometer (instrument cluster)
WL+IL	Off/On	<ul style="list-style-type: none"> • Off: Turns off all warning lights, indicator lights. • On: Illuminates all warning lights, indicator lights. 	Warning lights, indicator lights (instrument cluster)