

RVM WARNING ALARM


id092200031300

Purpose

- The rear vehicle monitoring warning alarm alerts the driver that there is a vehicle approaching in the lane which the driver is attempting to enter.

Function

- If the instrument cluster receives a warning sound request signal from the rear vehicle monitoring control module (RH), it sounds the rear vehicle monitoring warning alarm using the buzzer in the instrument cluster.
- The rear vehicle monitoring warning alarm sound pattern is as follows:




ac5wzn00001446

Construction

- The rear vehicle monitoring warning alarm sounds using the buzzer built into the instrument cluster.

Operation

- The instrument cluster receives (1) the warning sound request signal from the rear vehicle monitoring control module (RH).
- The instrument cluster turns the transistor on (2) based on the warning sound request signal.
- When the transistor turns on, a ground circuit with the alarm is established and the alarm sounds (3).



ac5wzn00001447

Fail-safe

- Function not equipped.