

---

## EGR COOLER BYPASS VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7217300

### Note

- Because the EGR cooler bypass valve position sensor is integrated in the EGR cooler bypass valve, replacing the EGR cooler bypass valve position sensor includes replacement of the EGR cooler bypass valve.

1. Remove the EGR cooler bypass valve. (See EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)