

DTC P06DA:00 [SKYACTIV-G 2.0]

id0102h1009300

DTC P06DA:00	Engine oil solenoid valve circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> The engine oil solenoid valve control current exceeds the specification or the control voltage at the PCM terminal 1AS is less than the specification relative to the PCM control condition. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none"> Engine oil solenoid valve connector or terminals malfunction Short to ground or open circuit in engine oil solenoid valve power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between ENGINE2 15 A fuse and engine oil solenoid valve terminal A ENGINE2 15 A fuse malfunction Open circuit in wiring harness between main relay terminal C and engine oil solenoid valve terminal A Short to ground in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1AS PCM connector or terminals malfunction Short to power supply in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1AS Open circuit in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1AS Engine oil solenoid valve malfunction PCM malfunction

MAIN RELAY TERMINAL C

ENGINE OIL SOLENOID VALVE

ENGINE OIL SOLENOID VALVE WIRING HARNESS-SIDE CONNECTOR

PCM

PCM WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	<div>Yes</div> Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"> If the vehicle is not repaired, go to the next step. <div>No</div> Go to the next step.

STEP	INSPECTION		ACTION
2	INSPECT ENGINE OIL SOLENOID VALVE CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the engine oil solenoid valve connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
3	INSPECT ENGINE OIL SOLENOID VALVE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve connector is disconnected. • Switch the ignition ON (engine off or on). • Measure the voltage at the engine oil solenoid valve terminal A (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE2 15 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 9.
4	INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve connector is disconnected. • Switch the ignition to off. • Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and body ground. • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 9.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and PCM connectors are disconnected. • Switch the ignition ON (engine off or on). • Measure the voltage at the engine oil solenoid valve terminal B (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.
7	INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and PCM connectors are disconnected. • Switch the ignition to off. • Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and PCM terminal 1AS (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT ENGINE OIL SOLENOID VALVE <ul style="list-style-type: none"> • Inspect the engine oil solenoid valve. (See ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the engine oil solenoid valve, then go to the next step. (See ENGINE OIL SOLENOID VALVE REMOVAL/ INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.