


CYLINDER BLOCK ASSEMBLY (II)

id011000504100

1. Assemble in the order indicated in the table.



bes2ze00000047


1	Oil strainer (See Balancer Component Assembly Note.)
2	Oil pump (See Balancer Component Assembly Note.)
3	Balancer unit (See Balancer Component Assembly Note.)
4	Balancer component (See Balancer Component Assembly Note.)
5	Oil pipe
6	Rear oil seal (See Rear Oil Seal Assembly Note.)

7	End plate (See End Plate Assembly Note.)
8	Dual-mass flywheel (MTX), drive plate (ATX)
9	Backing plate (ATX)
10	Dual-mass flywheel (MTX) / drive plate (ATX) installation bolt (See Dual-mass Flywheel Installation Bolt Assembly Note [MTX].) (See Drive Plate Installation Bolt Assembly Note [ATX].)

Balancer Component Assembly Note

Caution

- If the balancer shaft (No.1) spline is scratched or damaged, the engagement with the oil pump spline could worsen and it may not be possible to assemble the oil pump. Therefore, be careful not to scratch or damage the spline.
- Because the balancer shaft (No.1) journal slides with oil pump bearing, if the journal is scratched or damaged, the bearing could become damaged. Therefore, be careful not to scratch or damage the journal.




ac5wzw00004844

1. Apply clean engine oil to a new oil strainer O-ring.
2. Assemble the oil strainer to the oil pump.
3. Assemble the oil pump to the balancer unit using the following procedure:
 - (1) Verify that the balancer shaft (No.1) knock pin position is perpendicular to the cylinder block installation surface.
 - If the knock pin position has deviated, rotate the balancer shaft (No.1) and correct.
 - (2) Apply engine oil to the balancer shaft (No.1) journal area.
 - (3) Align the heights of the balancer shaft (No.1) spline and oil pump spline and install the oil pump to the balancer unit.


Note

- The balancer shaft (No.1) spline and oil pump spline timing does not need to be matched.
- (4) Temporarily tighten the bolts until the seating surfaces of the oil pump installation bolts are completely seated.




ac5wzw00004845

4. Assemble the balancer component using the following procedure:
 - (1) Install the oil pump and balancer unit to the cylinder block and temporarily tighten the seating face of the bolts shown in the figure until they are completely seated.



bes2ze00000048

(2) Tighten oil pump installation bolts in the order shown in the figure to the specified torque.




bes2ze00000049

Tightening torque

20—26 N·m {2.1—2.6 kgf·m, 15—19 ft·lbf}

(3) Tighten the balancer unit installation bolts in two steps in the order shown in the figure to the specified torque.




bes2ze00000050

Tightening procedure

Step 1: 16—22 N·m {1.7—2.2 kgf·m, 12—16 ft·lbf}

Step 2: 30—36 N·m {3.1—3.6 kgf·m, 23—26 ft·lbf}

(4) Tighten the oil pump installation bolts in the order shown in the figure.



ac5wzw00004849


Tightening torque

20—26 N·m {2.1—2.6 kgf·m, 15—19 ft·lbf}

Rear Oil Seal Assembly Note


1. Apply clean engine oil to the inner surface of a new rear oil seal.
2. Insert the rear oil seal into the cylinder block by hand.

3. Tap the oil seal in evenly using the **SST** and a hammer.



bes2ze00000051


Rear oil seal press-in amount
0—0.5 mm {0—0.019 in}



bes2ze00000052

End Plate Assembly Note

1. After end plate assembly, crimp the parts A and B shown in the figure.



bes2ze00000053

Crimp procedure

Crimp depth: 0.1—1.0 mm {0.004—0.039 in}

Crimp width: 0.5—10.0 mm {0.02—0.39 in}

Crimp locations: Part A is 1 or more on one-side within shaded area and part B is 2 or more within shaded areas

2. After crimping, verify that there is no damage and removal of the end plate.


Dual-mass Flywheel Installation Bolt Assembly Note [MTX]

1. Temporarily tighten the new bolts.

Note


- If the dual-mass flywheel (secondary flywheel side) is not positioned properly, perform the following procedure to install it:

- (1) Temporarily tighten the new bolts to the position as shown in the figure.



ac5wzw00005663

- (2) Install the **SST (49 S120 710)** to the dual-mass flywheel.
- (3) Rotate the dual-mass flywheel (secondary flywheel side) using the **SST (49 S120 710)**, and then temporarily tighten the remaining new bolt after removing the **SST (49 G033 102)**.




ac5wzw00005662

2. Hold the crankshaft using the **SST (49 E011 1A0)**.
3. Tighten the new bolts in two or three passes in the order shown in the figure.

Tightening torque

152—160 N·m {15.5—16.3 kgf·m, 113—118 ft·lbf}

49 E011 1A0



ac5wzw00005664


Drive Plate Installation Bolt Assembly Note [ATX]

1. Hold the crankshaft using the **SST**.
2. Tighten the new bolts in two or three passes in the order shown in the figure.

Tightening torque

108—116 N·m {11.1—11.8 kgf·m, 80—85 ft·lbf}

49 E011 1A0



ac5jjw00003091