

LUMBER SUPPORT MOTOR INSPECTION


id091300804300

Warning

- Handling a side air bag improperly can accidentally operate (deploy) the air bag, which may seriously injure you. Read the service warnings/cautions in the Workshop Manual before handling the front seat (side air bag integrated). (See AIR BAG SYSTEM SERVICE WARNINGS.) (See AIR BAG SYSTEM SERVICE CAUTIONS.)


L.H.D.

- Disconnect the negative battery cable and wait for **1 min or more**. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- Slide hooks A in the order of arrows (1), (2), (3) shown in the figure and disconnect them from hooks B.




ac5uuw00002049

- Open fasteners C.
- Disconnect the lumber support motor connector. Apply battery positive voltage to the lumber support motor terminals and inspect the front seat operation.
 - If not as specified, replace the lumber support motor. (See LUMBER SUPPORT MOTOR REMOVAL/INSTALLATION.)



ac5uuw00002050




ac5wzw00003153

Front seat operation	Connection	
	A	B
Forward	B+	GND

Front seat operation	Connection	
	A	B
Backward	GND	B+


R.H.D.

1. Disconnect the negative battery cable and wait for **1 min or more**. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
2. Slide hooks A in the order of arrows (1), (2), (3) shown in the figure and disconnect them from hooks B.




ac5uuw00002049

3. Open fasteners C.
4. Disconnect the lumber support motor connector. Apply battery positive voltage to the lumber support motor terminals and inspect the front seat operation.
 - If not as specified, replace the lumber support motor. (See LUMBER SUPPORT MOTOR REMOVAL/INSTALLATION.)



ac5uuw00002050



ac5wzw00003154

Front seat operation	Connection	
	A	B
Forward	GND	B+
Backward	B+	GND