


SECONDARY GEAR AND OUTPUT GEAR DISASSEMBLY

id051700661000

Structural View



bgw3ja00000204

1	Tapered roller bearing (transaxle case side)
2	Secondary gear
3	Tapered roller bearing (converter housing side)

4	Output gear
---	-------------

Disassembly Procedure

1. Perform the following inspection:


Caution

- If there is no malfunction based on the results of the inspection, it not necessary to disassemble the secondary gear and output gear.

- Visual inspection of parts (See VISUAL INSPECTION OF PARTS)
- Secondary gear and output gear inspection (See SECONDARY GEAR AND OUTPUT GEAR INSPECTION)
- If there is a malfunction, disassemble the secondary gear and output gear and replace the malfunctioning part with a new part.


2. Using the SST and press, remove the secondary gear and the tapered roller bearing (transaxle case side).

A : Press



azzjjw00000947

A : Tapered roller bearing (transaxle case side)
B : Secondary gear




azzjw00000948


3. Using the SSTs and press, remove the tapered roller bearing (converter housing side).

A : Press

4. Clean the disassembled parts. (See AUTOMATIC TRANSAXLE CLEANING.)



bgw3ja00000205



bgw3ja00000206