


DTC P0615:11 [START STOP UNIT]

id0902p6022000

System malfunction location	Starter relay circuit malfunction
Detection condition	• The start stop unit detects starter relay monitor circuit voltage of less than 2.2 V for 1 s or more with the ignition switched off.
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> • DTCs are stored in the PCM • Starter relay malfunction • Start stop unit connector or terminal malfunction • PCM connector malfunction • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — Starter relay terminal E—Start stop unit terminal 1D — Start stop unit terminal 1D—PCM terminal 2AZ (SKYACTIV-G 2.0, SKYACTIV-G 2.5) — Start stop unit terminal 1D—PCM terminal 2BF (SKYACTIV-D 2.2) — Starter relay terminal A—Start stop unit terminal 2V • Start stop unit malfunction



Diagnostic Procedure

Step	Inspection		Action
1	VERIFY PCM DTCs <ul style="list-style-type: none"> Perform the DTC inspection for the PCM using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Is the DTC displayed? 	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
2	INSPECT STARTER RELAY FOR MALFUNCTION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Remove the starter relay. (See RELAY LOCATION.) Inspect the starter relay. (See RELAY INSPECTION.) Is the starter relay normal? 	Yes	Go to the next step.
		No	Replace the starter relay, then go to Step 6. (See RELAY LOCATION.)
3	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the start stop unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
5	INSPECT STARTER RELAY CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the starter relay is removed. Verify that the start stop unit and PCM connectors are disconnected. Inspect for continuity between the following terminals (vehicle wiring harness side) and body ground. <ul style="list-style-type: none"> — Starter relay terminal E — Starter relay terminal A Is there continuity? 	Yes	Repair or replace the wiring harness which has a short to ground, then go to the next step.
		No	Go to the next step.

Step	Inspection	Action
6	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition to off and wait for 1 s or more. • Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is DTC P0615:11 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
7	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.