

---

## POWER WINDOW SYSTEM INITIALIZATION PROCEDURE

id091200004100

### Note

- If the following operations have been performed, initial setting is reset, and auto up/down operation are disabled. Therefore, performing initial setting is necessary.
  - Negative battery cable is disconnected.
  - Power window main switch connector is disconnected.
  - Power window system power supply fuse is removed.

1. Switch the ignition ON (engine off).
2. Press the driver's seat switch to fully open the door glass.
3. Pull up the driver's seat switch to the manual-up position to fully close the door glass and keep holding the switch up at the position for **approx. 2 s**.