

## COOLING FAN MOTOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0112h6801800

### Part Inspection

1. Verify that the battery is fully charged. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)  
(See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)
2. Disconnect the cooling fan motor connector (2 terminals).
3. Install a tester and battery to the cooling fan motor connector (2 terminals) as shown in the figure.
4. Verify that each cooling fan motor operates smoothly at the standard current.
  - If there is any malfunction, replace the applicable part.

**Cooling fan motor No.1, No.2 standard current**  
**4.5—8.5 A [12 V]**

