


CONDENSER REMOVAL/INSTALLATION

id071100801200

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
2. Discharge the refrigerant. (See REFRIGERANT CHARGING.)
3. Remove the front under cover No.1. (See FRONT UNDER COVER No.1 REMOVAL/INSTALLATION.)
4. Drain the engine coolant. (See ENGINE COOLANT REPLACEMENT [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)(See ENGINE COOLANT REPLACEMENT [SKYACTIV-D 2.2].)
5. Remove the following parts: (SKYACTIV-G 2.0, SKYACTIV-G 2.5)
 - (1) Plug hole plate (See PLUG HOLE PLATE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - (2) Air cleaner, air hose and fresh air duct component (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - (3) Coolant reserve tank (See COOLANT RESERVE TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - (4) Cooling fan component (See COOLING FAN MOTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
6. Remove the following parts: (SKYACTIV-D 2.2)
 - (1) Engine cover (See ENGINE COVER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
 - (2) Air cleaner and fresh air duct component (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
 - (3) Coolant reserve tank (See COOLANT RESERVE TANK REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
 - (4) Cooling fan component (See COOLING FAN MOTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
 - (5) Charge air cooler inlet hose and charge air cooler outlet hose (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
7. Disconnect the ATF oil cooler hose from the radiator. (if equipped) (SKYACTIV-D 2.2) (See OIL COOLER REMOVAL/INSTALLATION [GW6A-EL, GW6AX-EL].)
8. Remove the radiator. (See RADIATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)(See RADIATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
9. Remove the bolts.
10. Disconnect the cooler hose (HI) and cooler pipe. Do not allow remaining compressor oil in the refrigerant line to spill. (See REFRIGERANT LINE REMOVAL/INSTALLATION.)

Caution

- If moisture or foreign material enters the refrigeration cycle, cooling ability will be lowered and abnormal noise or other malfunction could occur. Always plug open fittings immediately after removing any refrigeration cycle parts.




ac5wzw00001808

11. Remove the condenser, being careful not to allow remaining compressor oil in the condenser to spill. (See Condenser Installation Note.)

Caution

- If moisture or foreign material enters the refrigeration cycle, cooling ability will be lowered and abnormal noise or other malfunction could occur. Always plug open fittings immediately after removing any refrigeration cycle parts.

12. Install in the reverse order of removal.
13. Inspect for engine coolant leakage. (See ENGINE COOLANT LEAKAGE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ENGINE COOLANT LEAKAGE INSPECTION [SKYACTIV-D 2.2].)
14. Inspect the ATF level. (if equipped) (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [GW6A-EL, GW6AX-EL].)
15. Perform the refrigerant system performance test. (See REFRIGERANT SYSTEM PERFORMANCE TEST.)



ac5wzw00001809

Condenser Installation Note

1. After replacing the condenser, add compressor oil to the refrigeration cycle.

Supplemental oil amount (approx. quantity)
13 ml {13 cc, 0.44 fl oz}