

AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0140g2899700

Warning

- A hot engine and exhaust system can cause severe burns. Turn off the engine and wait until they are cool before removing the exhaust system.


Caution

- Do not allow flammable objects such as the taping for bundling a wiring harness to come into contact with the exhaust manifold and silencer.




ac5wzw00000298

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)
2. Remove the plug hole plate. (See PLUG HOLE PLATE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
3. Disconnect the A/F sensor connector.
4. Remove the clip from the heat insulator.




ac5wzw000006372

5. Remove the wiring harness from the wire clips A and B. (See Assembly of Wiring Harness to Wire Clip Note.)



ac5wzw00000300


6. Remove the A/F sensor using the **SST**.
7. Install in the reverse order of removal.



ac5wzw00006373


Assembly of Wiring Harness to Wire Clip Note

- Secure the heat shrinkable tube on the wiring harness to wire clip A.



ac5wzw00000366

- Secure the band on the wiring harness so that the band is positioned on both sides of wire clip B.



ac5wzw00000367