




<b>DTC P0191:00</b>	<b>Fuel pressure sensor circuit range/performance problem</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>The difference between the actual and target fuel pressure is equal to or more than the specification, even though the fuel pressure feedback amount is maintained low or high.</li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>The DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Stops the high pressure fuel pump control.</li> <li>Limits the intake air amount.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Fuel pressure sensor connector or terminals malfunction</li> <li>Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>Fuel pressure sensor terminal C—PCM terminal 1BJ</li> <li>Fuel pressure sensor terminal B—PCM terminal 1CA</li> </ul> </li> <li>PCM connector or terminals malfunction</li> <li>Short to power supply in wiring harness between fuel pressure sensor terminal B and PCM terminal 1CA</li> <li>Fuel pressure sensor circuits are shorted to each other</li> <li>Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>Fuel pressure sensor terminal C—PCM terminal 1BJ</li> <li>Fuel pressure sensor terminal B—PCM terminal 1CA</li> <li>Fuel pressure sensor terminal A—PCM terminal 1CB</li> </ul> </li> <li>Fuel pressure sensor malfunction</li> <li>High pressure fuel pump malfunction</li> <li>PCM malfunction</li> </ul>



PCM WIRING HARNESS-SIDE CONNECTOR



## Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT FUEL PRESSURE SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the fuel pressure sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
4	<b>INSPECT FUEL PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure sensor connector is disconnected.</li> <li>Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>Fuel pressure sensor terminal C</li> <li>Fuel pressure sensor terminal B</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 11.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
6	<b>INSPECT FUEL PRESSURE SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure sensor and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off or on).</li> <li>Measure the voltage at the fuel pressure sensor terminal B (wiring harness-side).</li> <li>Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 11.
7	<b>INSPECT FUEL PRESSURE SENSOR CIRCUITS FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure sensor and PCM connectors are disconnected.</li> <li>Switch the ignition to off.</li> <li>Inspect for continuity between fuel pressure sensor terminals C, B and A (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 11.
		No	Go to the next step.
8	<b>INSPECT FUEL PRESSURE SENSOR CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure sensor and PCM connectors are disconnected.</li> <li>Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>Fuel pressure sensor terminal C—PCM terminal 1BJ</li> <li>Fuel pressure sensor terminal B—PCM terminal 1CA</li> <li>Fuel pressure sensor terminal A—PCM terminal 1CB</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 11.

STEP	INSPECTION		ACTION
9	<b>INSPECT FUEL PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>• Reconnect all disconnected connectors.</li> <li>• Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the fuel distributor, then go to Step 11. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
10	<b>INSPECT HIGH PRESSURE FUEL PUMP</b> <ul style="list-style-type: none"> <li>• Inspect the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.0].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the high pressure fuel pump, then go to the next step. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
11	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Make sure to reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>• Start the engine and warm it up completely.</li> <li>• Increase and keep the engine speed at <b>3,000 rpm</b> for <b>1 min</b>.</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
12	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.