

DTC P0198:00	Engine oil temperature sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the engine oil temperature sensor signal. If the PCM detects that the engine oil temperature sensor voltage at the PCM terminal 1DI is above 4.9 V for 1 s, the PCM determines that the engine oil temperature sensor circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> The fast idle up correction for the idle speed control is inhibited. Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Engine oil temperature sensor/engine oil pressure sensor connector or terminals malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between engine oil temperature sensor/engine oil pressure sensor terminal E and PCM terminal 1DI Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Engine oil temperature sensor/engine oil pressure sensor terminal E—PCM terminal 1DI Engine oil temperature sensor/engine oil pressure sensor terminal C—PCM terminal 1DJ Engine oil temperature sensor malfunction PCM malfunction

⑦

ENGINE OIL TEMPERATURE SENSOR
(ENGINE OIL TEMPERATURE SENSOR/
ENGINE OIL PRESSURE SENSOR)

ENGINE OIL TEMPERATURE SENSOR/
ENGINE OIL PRESSURE SENSOR
WIRING HARNESS-SIDE
CONNECTOR

PCM

PCM WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the engine oil temperature sensor/ engine oil pressure sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to Step 8.
		No Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to Step 8.
		No Go to the next step.
5	INSPECT ENGINE OIL TEMPERATURE SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the engine oil temperature sensor/ engine oil pressure sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the engine oil temperature sensor/engine oil pressure sensor terminal E (wiring harness-side). Is the voltage 0 V? 	Yes Go to the next step.
		No Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
6	INSPECT ENGINE OIL TEMPERATURE SENSOR SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the engine oil temperature sensor/ engine oil pressure sensor and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Engine oil temperature sensor/engine oil pressure sensor terminal E—PCM terminal 1DI Engine oil temperature sensor/engine oil pressure sensor terminal C—PCM terminal 1DJ Is there continuity? 	Yes Go to the next step.
		No Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
7	INSPECT ENGINE OIL TEMPERATURE SENSOR <ul style="list-style-type: none"> Inspect the engine oil temperature sensor. (See ENGINE OIL TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes Replace the engine oil temperature sensor/engine oil pressure sensor, then go to the next step. (See ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No Go to the next step.

STEP	INSPECTION	ACTION	
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.