


IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0]

id0118h6811200

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0 (WITHOUT i-stop)])
2. Remove the plug hole plate. (See PLUG HOLE PLATE REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

1	Connector
2	Ignition coil/ion sensor



ac5uuw00000602