


DTC P0193:00	Fuel pressure sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> If the input voltage at the PCM terminal 1CA is more than 4.86 V for 5 s, the PCM determines that the fuel pressure sensor circuit is high. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Stops the high pressure fuel pump control. Limits the intake air amount.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Fuel pressure sensor connector or terminals malfunction PCM connector or terminals malfunction Fuel pressure sensor malfunction Short to power supply in wiring harness between fuel pressure sensor terminal B and PCM terminal 1CA Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Fuel pressure sensor terminal B—PCM terminal 1CA Fuel pressure sensor terminal A—PCM terminal 1CB Fuel pressure sensor terminal C—PCM terminal 1BJ PCM malfunction



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	CLASSIFY FUEL PRESSURE SENSOR MALFUNCTION OR WIRING HARNESS MALFUNCTION <ul style="list-style-type: none"> • Access the FUEL_PRES PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) • Verify the FUEL_PRES PID value. • Is the FUEL_PRES PID value 5 V or B+? 	Yes	When the voltage is 5V <ul style="list-style-type: none"> • Go to Step 7. When the voltage is B+ <ul style="list-style-type: none"> • Go to Step 8.
		No	Go to the next step.
4	INSPECT FUEL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the fuel pressure sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the fuel distributor, then go to Step 9. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to Step 9.
7	INSPECT FUEL PRESSURE SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the fuel pressure sensor connector and PCM connector. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Fuel pressure sensor terminal B—PCM terminal 1CA — Fuel pressure sensor terminal A—PCM terminal 1CB — Fuel pressure sensor terminal C—PCM terminal 1BJ • Is there continuity? 	Yes	Replace the fuel distributor, then go to Step 9. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT FUEL PRESSURE SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the fuel pressure sensor connector and PCM connector. • Measure the voltage at the fuel pressure sensor terminal B (wiring harness-side). • Is there any voltage? 	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Replace the fuel distributor, then go to the next step. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.